



General Motor® Global 2008~2014 Cover the models listed in GDS®, read / clear DTC / live data and adaptation

VERSION: 2015.01 DATE: January, 2015

MODEL	SYSTEM LIST
Aveo	Powertrain, Chassis, Body
Beat	Powertrain, Chassis, Body
Cruze	Powertrain, Chassis, Body
Camaro	Powertrain, Chassis, Body
Captiva	Powertrain, Chassis, Body
Cobalt	Powertrain, Chassis, Body
Colorado	Powertrain, Chassis, Body
Caprice	Powertrain, Chassis, Body
Cheyenne	Powertrain, Chassis, Body
Corvette	Powertrain, Chassis, Body
Enjoy	Powertrain
Equinox	Powertrain, Chassis, Body
Express	Powertrain, Chassis, Body
HHR(Europe)	Powertrain, Chassis, Body
Impala	Powertrain, Chassis, Body
Lacetti	Powertrain
Lumina	Powertrain, Chassis, Body
Malibu	Powertrain, Chassis, Body
N300	Powertrain, Chassis
Onix	Powertrain, Chassis, Body
Optra	Powertrain, Chassis, Body
Orlando	Powertrain, Chassis, Body
Prisma	Powertrain, Chassis, Body
Sail	Powertrain, Chassis, Body



MODEL	SYSTEM LIST
Spin	Powertrain, Chassis, Body
Spark	Powertrain, Chassis, Body
Spark EV	Powertrain, Chassis, Body
Savana	Powertrain, Chassis, Body
Silverado	Powertrain, Chassis, Body
SS	Powertrain, Chassis, Body
Suburban	Powertrain, Chassis, Body
S10	Powertrain, Chassis, Body
Sonic	Powertrain, Chassis, Body
Tavera	Powertrain
Tracker	Powertrain, Chassis, Body
Trailblazer	Powertrain, Chassis, Body
Trax	Powertrain, Chassis, Body
Tahoe	Powertrain, Chassis, Body
Traverse	Powertrain, Chassis, Body
Volt	Powertrain, Chassis, Body



Aveo 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
NGINE	1.2L(LDC)	✓	✓	✓	✓
	1.2L(LWD)	✓	✓	✓	~
	1.3L(LDV)	✓	✓	✓	~
	1.3L(LSF)	✓	✓	✓	~
	1.4L(L2N)	✓	✓	✓	~
	1.4L(LCU)	✓	•	✓	~
	1.4L(LDD)	✓	•	✓	~
	1.4L(LUJ)	✓	✓	✓	~
	1.4L(LUV)	✓	•	✓	~
	1.6L(LDE)	✓	✓	✓	~
	1.6L(LED)	✓	•	•	~
	1.6L(LFJ)	✓	✓	✓	~
	Fuel Injector Control Module	•			
	Chassis Control Module	✓	✓		~
RANSMISSION	Transmission Control Module	•	•	✓	•
HASSIS	Electronic Brake Control Module	~	•	✓	•
	Multi-Axis Acceleration Sensor Module		•		•
	Power Steering Control Module	~	•		
	Steering Wheel Angle Sensor		·		•

GM[®] Global – Page 3



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Instrument Cluster	✓	•	✓	
	HVAC Control Module	✓	✓	✓	
	Front Seat Heating Control Module	•	•	~	
	Parking Assist Control Module	•	•		



Aveo 2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LDC)	✓	•	~	~
	1.2L(LWD)	~	•	✓	✓
	1.3L(LDV)	~	•	✓	✓
	1.3L(LSF)	~	•	✓	✓
	1.4L(L2N)	✓	•	✓	✓
	1.4L(LDD)	~	•	✓	•
	1.6L(LDE)	~	•	✓	•
	1.6L(LFJ)	~	•	✓	•
	Fuel Injector Control Module	~			
	Chassis Control Module	~	•		✓
FRANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Power Steering Control Module	~	•		
	Steering Wheel Angle Sensor		•		v



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	✓	•	✓	•
	Passenger Presence Module	~	•		•
	Instrument Cluster	✓	•	✓	
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	✓	
	Front Seat Heating Control Module	~	•	~	
	Parking Assist Control Module	~	•		



Aveo 2012

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LDC)	✓	✓	✓	✓
	1.2L(LWD)	✓	•	✓	✓
	1.3L(LDV)	✓	•	✓	✓
	1.3L(LSF)	✓	•	✓	~
	1.4L(LCU)	✓	•	✓	✓
	1.4L(LDD)	✓	•	✓	✓
	1.6L(LDE)	✓	•	✓	✓
	1.6L(LFJ)	✓	•	✓	✓
	1.8L(LUW)	✓	•	✓	✓
	Fuel Injector Control Module	~			
	Fuel Pump Control Module	✓	✓		✓
TRANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Power Steering Control Module	V	•		
	Steering Wheel Angle Sensor		•		V



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	✓	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	~	~	~
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	~	
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	~	
	Front Seat Heating Control Module	~	•	~	
	Parking Assist Control Module	~	•		

Beat 2010~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.0L(LEB)	✓	✓	✓	•
	1.19L(LC5)	✓	✓		
TRANSMISSION	Transmission Control Module		•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•		
	Multi-Axis Acceleration Sensor Module		•		•
	Electric Power Steering Control Mosule	•	•		
	Steering Wheel Angle Sensor		•		~
BODY	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•		~
	Instrument Cluster	•	•	•	

Camaro 2014

<u> </u>					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	3.6L(LFX)	✓	•	✓	•
	6.2L(L99)	✓	✓	✓	•
	6.2L(LS3)	✓	✓	✓	•
	6.2L(LSA)	✓	✓	✓	•
	7.0L(LS7)	✓	•	✓	•
	Chassis Control Module	✓	•		✓
TRANSMISSION	Transmission Control Module	✓	✓	✓	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Power Steering Control Mosule	•	•		•
	Steering Wheel Angle Sensor		•		~
	Suspension Control Module	✓	✓		
BODY	Body Control Module	✓	✓	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	✓	•		~
	Instrument Cluster	✓	•	✓	✓
	Auxiliary Gage Module	✓	✓		
	Headlamp Control Module	✓	✓	✓	✓
	Radio	✓	✓	✓	
	Telematic Vehicle Localization and Immobilizer	~	•	~	
	HVAC Control Module	✓	✓	✓	✓
	Front Seat Heating Control Module	~	•	~	
	Parking Assist Control Module	✓	•		



Camaro 2012~2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	3.6L(LFX)	✓	~	✓	✓
	6.2L(L99)	✓	•	✓	✓
	6.2L(LS3)	✓	•	✓	✓
	6.2L(LSA)	✓	•	✓	•
	Fuel Pump Control Module	✓	•		•
TRANSMISSION	Transmission Control Module	~	•	•	•
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Multi-Axis Acceleration Sensor Module		•		~
	Power Steering Control Mosule	~	•		•
	Steering Wheel Angle Sensor		•		~
	Suspension Control Module	•	•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	•
	Auxiliary Gage Module	✓	•		
	Radio	✓	•	✓	
	Telematic Vehicle Localization and Immobilizer	~	•	~	
	Remote Heater and A/C Control Module	~	•	•	•
	Front Seat Heating Control Module	•	•	•	
	Parking Assist Control Module	~	•		



Camaro 2010~2011

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	3.6L(LLT)	✓	•	✓	•
	6.2L(L99)	✓	•	✓	•
	6.2L(LS3)	✓	•	✓	•
	Fuel Pump Control Module	✓	•		•
TRANSMISSION	Transmission Control Module	•	•	•	~
CHASSIS	Electronic Brake Control Module	~	•	•	•
	Multi-Axis Acceleration Sensor Module		•		~
	Power Steering Control Mosule	•	•		~
	Steering Wheel Angle Sensor		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	~	•		•
	Instrument Cluster	✓	•	✓	•
	Auxiliary Gage Module	✓	•		
	Radio	✓	•	✓	
	Telematic Vehicle Localization and Immobilizer	~	•	~	
	Remote Heater and A/C Control Module	~	•	~	•
	Front Seat Heating Control Module	•	•	•	
	Parking Assist Control Module	~	•		

Caprice 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	3.6L(LFX)	✓	✓	✓	•
	6.0L(L77)	✓	✓	✓	•
TRANSMISSION	Transmission Control Module	•	•	•	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Parking Brake Control Module	~	•	~	•
	Power Steering Control Module	~	•		•
	Steering Wheel Angle Sensor Module		•		~
BODY	Body Control Module	✓	✓	~	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	~	•		~
	Instrument Cluster	~	•	✓	
	Radio Controls	✓	•		✓
	HVAC Controls	✓	✓		~
	Headlamp Control Module	✓	✓	~	~
	Trailer Interface Control Module	~	•	~	
	Radio	✓	✓	~	
	HVAC Control Module	✓	✓	~	~
	Parking Assist Control Module	~	•	~	
	Steering Column Lock Control Module	~	•		



Captiva 2013~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.0L(LNP)	✓	✓	~	~
	2.2L(LNQ)	✓	•	✓	~
	2.4L(LE5)	✓	•	~	~
	2.4L(LE9)	✓	•	✓	~
	2.4L(LEA)	✓	•	~	~
	3.0L(LFW)	✓	•	✓	~
	Chassis Control Module	✓	•		~
TRANSMISSION	Transmission Control Module	•	•	~	•
	Rear Differential Clutch Control Module	•	•	~	
CHASSIS	Electronic Brake Control Module	•	~	V	~
	Parking Brake Control Module	•	•	~	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	~
	Auxiliary Body Control Module	~	•	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	~	~	~
	Instrument Cluster	✓	•	✓	
	Headlamp Control Module	✓	•	✓	•
	HVAC Control Module		•	✓	
	Remote Control Door Lock Receiver	~	•	•	~
	Parking Assist Control Module	•	•	~	
	Theft Deterrent Module	✓	~		



Captiva 2012

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.0L(LNP)	✓	•	✓	~
	2.2L(LNQ)	✓	•	✓	•
	2.4L(LE5)	✓	•	✓	•
	2.4L(LE9)	✓	•	✓	•
	3.0L(LF1)	✓	•	✓	~
	3.0L(LFW)	✓	•	✓	•
	Fuel Pump Control Module	✓	•		~
TRANSMISSION	Transmission Control Module	•	•	~	•
	Rear Differential Clutch Control Module	~	•	~	
CHASSIS	Electronic Brake Control Module	~	•	✓	•
	Parking Brake Control Module	•	•	•	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Auxiliary Body Control Module	~	•	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Instrument Cluster	✓	•	✓	
	Headlamp Control Module	✓	•	✓	•
	HVAC Control Module		•	✓	
	Remote Control Door Lock Receiver	~	•	•	•
	Parking Assist Control Module	~	•	~	
	Theft Deterrent Module	✓	•		



Captiva 2011

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.0L(LNP)	✓	•	~	•
	2.2L(LNQ)	✓	•	~	•
	2.4L(LE5)	✓	•	~	•
	2.4L(LE9)	✓	•	~	•
	3.0L(LF1)	✓	•	~	•
	Fuel Pump Control Module	✓	•		•
TRANSMISSION	Transmission Control Module	~	•	~	~
	Rear Differential Clutch Control Module	•	•	~	
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Parking Brake Control Module	~	•	~	~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Auxiliary Body Control Module	~	•	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Instrument Cluster	✓	✓	✓	
	Headlamp Control Module	✓	✓	✓	•
	HVAC Control Module		✓	✓	
	Remote Control Door Lock Receiver	~	•	~	•
	Parking Assist Control Module	~	•	~	
	Theft Deterrent Module	✓	•		

Cheyenne 2014

Cheyenne 2014					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	4.3L(LV1)	✓	•	✓	•
	4.3L(LV3)	✓	•	✓	•
	5.3L(L83)	✓	•	✓	•
	6.0L(L96)	✓	•	✓	•
	6.2L(L86)	✓	•	✓	•
	Chassis Control Module	✓	•	✓	



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
TRANSMISSION	Transmission Control Module	•	•	•	•
	Transfer case Control Module	~	•	~	~
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Parking Brake Control Module	~	•	✓	~
	Power Steering Control Module	~	•	✓	~
	Steering Wheel Angle Sensor Module		•		~
ODY	Body Control Module	✓	•	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	•	•	•	•
	Passenger Presence Module	~	•	~	~
	Instrument Cluster	✓	✓	✓	
	Radio Controls	✓	v		
	HVAC Controls	✓	✓	✓	
	Radio	✓	✓	✓	~
	Amplifier	✓	~	✓	~
	HVAC Control Module	✓	✓	✓	~
	Left Side Object Detection Control Module	~	V	~	
	Parking Assist Control Module	~	~	•	



Cobalt 2013~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.3L(LDV)	✓	•	✓	~
	1.4L(LKF)	✓	✓	✓	✓
	1.5L(L2C)	✓	✓	✓	✓
	1.8L(LJ1)	✓	✓	✓	✓
	1.8L(LMD)	✓	✓	✓	✓
FRANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		~		~
	Steering Wheel Angle Sensor		~		~
BODY	Body Control Module	✓	✓	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	~	V	•
	Instrument Cluster	✓	✓	✓	
	Radio	✓	✓	✓	
	HVAC Control Module	✓	✓	✓	
	Front Seat Heating Control Module	•	~	~	
	Parking Assist Control Module	~	~		



Cobalt 2012

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.3L(LDV)	✓	✓	✓	✓
	1.3L(LSF)	✓	✓	✓	✓
	1.4L(LKF)	✓	✓	~	~
	1.8L(LJ1)	✓	✓	✓	~
TRANSMISSION	Transmission Control Module	V	•	~	~
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Electric Power Steering Control Module	~	•		
	Steering Wheel Angle Sensor		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	~	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	~	V	•
	Passenger Presence Module	~	~		•
	Instrument Cluster	✓	~	~	
	Radio	✓	~	~	
	HVAC Control Module	✓	~	~	
	Front Seat Heating Control Module	~	~	~	
	Parking Assist Control Module	~	~		

Colorado 2013~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LE6)	✓	•	✓	•
	2.5L(LKH)	✓	•	✓	✓
	2.8L(LWH)	✓	•	✓	•
	3.6L(LY7)	✓	•	✓	✓
TRANSMISSION	Transmission Control Module	•	•	•	•
	Transfer Case Control Module	•	•	~	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•		•
	Instrument Cluster	✓	•	✓	

Colorado 2012

Sciolago 2012					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LE6)	•	•	✓	•
	2.5L(LVN)	✓	✓	✓	~
	2.8L(LWH)	✓	•	✓	~
	3.6L(LY7)	•	•	✓	•
TRANSMISSION	Transmission Control Module	~	•	•	•
	Transfer Case Control Module	~	•	•	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•		•
	Instrument Cluster	✓	•	✓	
	Trailer Interface Control Module	~	•	~	

Corvette 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	•	✓	✓	✓
	Chassis Control Module	✓	✓	✓	✓
TRANSMISSION	Transmission Control Module	•	•	•	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	v	•
	Parking Brake Control Module	•	•	~	•
	Power Steering Control Module	•	•		
	Steering Wheel Angle Sensor Module		•		•
	Suspension Control Module	•	•	~	•
BODY	Body Control Module	✓	✓	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•	~	•
	Instrument Cluster	✓	•	✓	
	Radio Controls	✓	•		
	HVAC Controls	✓	•	~	
	Radio	✓	•	~	✓
	Amplifier		✓		
	HVAC Control Module	✓	•	~	✓
	Left Side Object Detection Control Module	~	•	~	
	Parking Assist Control Module	~	•	~	



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LDD)	✓	✓	✓	✓
	1.4L(LUJ)	✓	•	~	~
	1.4L(LUV)	✓	•	✓	•
	1.6L(L2W)	✓	•	~	✓
	1.6L(LDE)	✓	•	✓	•
	1.6L(LLU)	✓	•	~	✓
	1.6L(LXT)	•	•	~	•
	1.7L(LKR)	•	•	✓	✓
	1.7L(LUD)	✓	•	✓	•
	1.8L(2H0)	✓	•	~	✓
	1.8L(LFH)	✓	•	✓	•
	1.8L(LUW)	✓	•	~	✓
	1.8L(LWE)	•	•	~	•
	2.0L(LNP)	✓	•	~	✓
	2.0L(LUZ)	✓	•	✓	•
	Fuel Injector Control Module	•			
TRANSMISSION	Transmission Control Module	•	•	~	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
	Power Steering Control Mosule	~	•		•
BODY	Body Control Module	✓	•	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	~	•		•
	Instrument Cluster	✓	•	✓	✓
	Trailer Interface Control Module	~	•	~	•
	Radio	✓	•	~	
	HVAC Control Module	✓	•	~	✓
	Front Seat Heating Control Module	~	•	V	
	Keyless Entry Control Module	~	•	V	
	Parking Assist Control Module	~	•		
	Steering Column Lock Control Module	~	•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LDD)	~	•	~	✓
	1.4L(LUJ)	~	•	✓	✓
	1.4L(LUV)	~	•	✓	~
	1.6L(L2W)	~	•	✓	~
	1.6L(LDE)	~	•	✓	•
	1.6L(LXT)	~	•	✓	~
	1.7L(LUD)	~	•	✓	~
	1.8L(2H0)	✓	✓	✓	~
	1.8L(LFH)	~	✓	✓	•
	1.8L(LUW)	~	•	✓	✓
	1.8L(LWE)	~	✓	✓	•
	2.0L(LNP)	✓	✓	✓	✓
RANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	~	~	~
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	✓	✓	•
	Trailer Interface Control Module	•	•	~	•
	Radio	✓	✓	✓	
	HVAC Control Module	✓	•	✓	•
	Front Seat Heating Control Module	•	~	~	
	Keyless Entry Control Module	•	•	•	
	Parking Assist Control Module	•	~		
	Steering Column Lock Control Module	~	•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LUJ)	~	→	~	✓
	1.6L(L2W)	✓	•	✓	✓
	1.6L(LDE)	~	→	✓	✓
	1.6L(LXT)	✓	•	✓	✓
	1.7L(LUD)	~	→	✓	✓
	1.8L(2H0)	✓	•	✓	✓
	1.8L(LFH)	✓	→	✓	✓
	1.8L(LUW)	✓	•	✓	✓
	2.0L(LLW)	~	→	✓	✓
	2.0L(LNP)	✓	✓	✓	✓
FRANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	~	•
	Inflatable Restraint Sensing and Diagnostic Module	•	~	V	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	•
	Trailer Interface Control Module	•	•	~	•
	Radio	✓	•	~	
	Remote Heater and A/C Control Module	•	•	~	•
	Keyless Entry Control Module	•	•	V	
	Parking Assist Control Module	•	•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LUJ)	~	✓	✓	✓
	1.6L(L2W)	~	•	~	•
	1.6L(LDE)	~	•	~	~
	1.6L(LXT)	~	•	~	~
	1.8L(2H0)	~	•	~	~
	1.8L(LUW)	~	•	✓	~
	2.0L(LLW)	~	•	✓	~
	2.0L(LNP)	~	•	✓	~
TRANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	✓
	Trailer Interface Control Module	•	•	•	•
	Radio	✓	•	✓	
	Remote Heater and A/C Control Module	•	•	~	•
	Keyless Entry Control Module	•	•	✓	
	Parking Assist Control Module	•	•		



Cruze 2010

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.6L(LXT)	✓	✓	✓	✓
	1.6L(LXV)	✓	✓	✓	•
	1.8L(2H0)	✓	✓	✓	•
	2.0L(LLW)	✓	✓	✓	•
TRANSMISSION	Transmission Control Module	•	•	•	•
CHASSIS	Electronic Brake Control Module	•	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	~
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	•
	Trailer Interface Control Module	•	•	•	•
	Radio	✓	✓	✓	
	Remote Heater and A/C Control Module	•	•	•	•
	Keyless Entry Control Module	•	•	•	
	Parking Assist Control Module	•	•		

Enjoy 2012~2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.3L(LDV)	✓	✓	✓	•



Equinox 2013~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LEA)	✓	•	✓	•
	3.6L(LFX)	✓	•	~	✓
TRANSMISSION	Transmission Control Module	•	•	~	•
	Rear Differential Clutch Control Module	~	•		•
CHASSIS	Electronic Brake Control Module	•	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		~
	Power Steering Control Module	~	•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	~
	Passenger Presence Module	~	•		•
	Instrument Cluster	✓	•	✓	•
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	✓	•
	Liftgate Control Module	✓	•		
	Parking Assist Control Module	~	•		
	Front Seat Heating Control Module	•	•	•	

Equinox 2011~2012

Equilities 2011~201					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LEA)	✓	•	~	~
	3.0L(LFW)	✓	•	✓	~
	Fuel Pump Control Module	✓	•		~
TRANSMISSION	Transmission Control Module	~	•	~	~
	Rear Differential Clutch Control Module	~	•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	•	✓	~	~
	Inflatable Restraint Sensing and Diagnostic Module	•	•	✓	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	•	•	~	~
	Radio	•	•	✓	
	Remote Heater and A/C Control Module	~	•	~	•
	Liftgate Control Module	•	✓		
	Parking Assist Control Module	~	•		

Equinox 2010

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LEA)	✓	•	✓	✓
	3.0L(LF1)	✓	•	✓	~
	Fuel Pump Control Module	✓	•		✓



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
TRANSMISSION	Transmission Control Module	•	•	~	•
	Rear Differential Clutch Control Module	•	•		•
CHASSIS	Electronic Brake Control Module	•	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	•	•	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	•
	Radio	•	•	~	
	Remote Heater and A/C Control Module	~	•	V	•
	Liftgate Control Module	•	•		
	Parking Assist Control Module	~	•		



Express 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	4.3L(LU3)	~	✓	✓	~
	4.8L(L20)	✓	✓	✓	✓
	5.3L(LMF)	✓	~	✓	✓
	6.0L(L96)	~	~	✓	✓
	6.0L(LC8)	✓	✓	✓	✓
	6.6L(LGH)	~	✓	✓	✓
	Glow Plug Control Module	~	✓	✓	•
TRANSMISSION	Transmission Control Module	~	~	~	~
CHASSIS	Electronic Brake Control Module	~	•	✓	~
BODY	Body Control Module	~	✓	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	•	•	•
	Passenger Presence Module	~	•		
	Rollover Sensor Module	~	✓		
	Instrument Cluster	~	✓	✓	
	Chime Alarm Control Module	~		✓	
	Auxiliary Heater Control Module	~	•	~	
	Parking Assist Control Module	~	•	~	
	Theft Deterrent Module	✓	✓		



HHR(Europe) 2008~2009

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	✓	•	✓	•
TRANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Electric Power Steering Control Module	•	•		
BODY	Body Control Module	✓	✓	✓	
	Inflatable Restraint Sensing and Diagnostic Module	•	•		~
	Instrument Cluster	✓	•	✓	
	Radio	✓	•	✓	
	Keyless Entry Control Module	•	•	~	•
	Immobilizerbilizer Control Module	~	•		



Impala 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LUK)	✓	•	~	✓
	2.5L(LKW)	✓	•	~	✓
	3.6L(LFX)	✓	•	~	✓
	Chassis Control Module	✓	•		✓
	Hybrid Powertrain Control Module	~	•	V	•
TRANSMISSION	Transmission Control Module	•	•	~	~
	Drive Motor Control Module	•			
CHASSIS	Electronic Brake Control Module	~	•	V	•
	Distance Sensing Cruise Control Module	~	•		•
	Parking Brake Control Module	•	•	~	~
	Steering Wheel Angle Sensor Module		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	~	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	~	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	~	✓
	Radio Controls	✓	~		
	HVAC Controls	✓	✓	✓	
	Radio	✓	•	✓	•
	Amplifier		✓		
	HVAC Control Module	✓	✓	✓	✓
	Keyless Entry Control Module	•	•	~	
	Right Side Object Detection Control Module		•	~	
	Left Side Object Detection Control Module		•	~	
	Parking Assist Control Module	•	•	~	
	Steering Column Lock Control Module	~	•		
	Battery Energy Control Module(2.4L)	~			



Lacetti 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.5L(L2C)	•	✓	✓	•
	1.5L(LM9)	✓	✓	✓	•
TRANSMISSION	Transmission Control Module	~	•	~	•

Lumina 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	•	•	✓	✓
	Chassis Control Module	✓	✓		✓
TRANSMISSION	Transmission Control Module	•	•	•	•
CHASSIS	Electronic Brake Control Module	•	•	~	•
	Parking Brake Control Module	•	•	•	•
	Power Steering Control Module	•	•		•
	Steering Wheel Angle Sensor Module		•		•
	Suspension Control Module	•	•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	~	✓	~	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	~
	Instrument Cluster	~	✓	~	
	Radio Controls	~	✓		•
	HVAC Controls	~	~		•
	Headlamp Control Module	~	✓	~	•
	Trailer Interface Control Module	~	•	~	
	Radio	~	✓	~	
	HVAC Control Module	~	✓	~	•
	Keyless Entry Control Module	~	•	~	
	Parking Assist Control Module	~	•	~	
	Steering Column Lock Control Module	v	~		



Malibu 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.0L(LBN)	✓	✓	~	•
	2.0L(LBS)	✓	✓	~	•
	2.0L(LBY)	✓	✓	✓	•
	2.0L(LTD)	✓	✓	~	•
	2.0L(LTG)	✓	✓	✓	•
	2.4L(LE9)	✓	✓	~	•
	2.4L(LUK)	✓	~	✓	✓
	2.5L(LKW)	✓	~	~	~
	3.0L(LFW)	✓	~	~	~
	Fuel Injector Control Module	✓	•	~	
	Chassis Control Module	✓	~		
	Hybrid Powertrain Control Module	~	•	~	•
FRANSMISSION	Transmission Control Module	~	•	~	•
	Drive Motor Control Module	~			
CHASSIS	Electronic Brake Control Module	~	•	✓	•
	Parking Brake Control Module	•	v	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		·		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	~	•	~	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	~
	Passenger Presence Module	~	•		•
	Instrument Cluster	~	•	~	✓
	Headlamp Control Module	~	•	✓	•
	Radio	✓	•	✓	
	HVAC Control Module	~	•	✓	•
	Seat Memory Control Module	~	•	~	•
	Front Seat Heating Control Module	~	•	~	
	Rear Seat Heating Control Module	~	•	~	
	Keyless Entry Control Module	~	•	~	
	Parking Assist Control Module	~	•	~	
	Steering Column Lock Control Module	~	•		



Malibu 2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.0L(LBN)	✓	•	✓	~
	2.0L(LBS)	•	•	✓	~
	2.0L(LBY)	•	•	✓	~
	2.0L(LTD)	•	•	~	~
	2.0L(LTG)	•	•	~	✓
	2.4L(LE9)	•	•	~	✓
	2.4L(LUK)	•	✓	~	✓
	2.5L(LCV)	•	✓	✓	✓
	3.0L(LFW)	•	✓	~	✓
	Fuel Injector Control Module	~	•	~	
TRANSMISSION	Transmission Control Module	~	•	~	•
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Parking Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Power Steering Control Module		•		
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	✓
	Headlamp Control Module	✓	•	✓	•
	Radio	✓	~	✓	
	HVAC Control Module	✓	~	✓	~
	Seat Memory Control Module	•	•	~	•
	Front Seat Heating Control Module	•	•	•	
	Rear Seat Heating Control Module	•	•	✓	
	Keyless Entry Control Module	~	•	~	
	Parking Assist Control Module	~	•	~	
	Steering Column Lock Control Module	~	•		



Malibu 2012

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.0L(LBN)	~	•	✓	•
	2.0L(LBS)	~	•	✓	•
	2.0L(LTD)	~	•	✓	✓
	2.4L(LE9)	~	•	✓	~
	3.0L(LFW)	~	•	✓	~
TRANSMISSION	Transmission Control Module	~	•	~	~
	Rear Differential Clutch Control Module	~	•	•	
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Parking Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Power Steering Control Module		•		
	Steering Wheel Angle Sensor		•		V



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	~	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	✓	✓	✓
	Head-Up Display Module	•	•	✓	
	Headlamp Control Module	✓	✓	✓	✓
	Radio	✓	•	✓	
	Remote Heater and A/C Control Module	•	~	~	~
	Seat Memory Control Module	•	•	~	•
	Front Seat Heating Control Module	~	•	~	
	Rear Seat Heating Control Module	•	•	~	
	Keyless Entry Control Module	~	~	~	
	Right Side Object Detection Control Module	•	~	~	
	Left Side Object Detection Control Module	~	~	~	
	Parking Assist Control Module	~	•	~	
	Steering Column Lock Control Module	~	~		



N300 2013~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	✓	✓	✓	•
CHASSIS	Electronic Brake Control Module	~	•	•	

Onix 2013~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.0L(LKL)	✓	•	✓	•
	1.4L(LKJ)	✓	•	✓	~
	1.4L(LKK)	✓	•	✓	~
TRANSMISSION	Transmission Control Module	•	•	~	•
CHASSIS	Electronic Brake Control Module	•	•	~	
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	•	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Instrument Cluster	✓	•	✓	
	Radio	✓			
	Parking Assist Control Module	~	•		



Optra 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.5L(L2B)	✓	•	✓	•
	1.8L(2H0)	~	✓	✓	•
TRANSMISSION	Transmission Control Module	•	•	•	•
CHASSIS	Electronic Brake Control Module	•	•	~	
BODY	Body Control Module	✓	✓	✓	
	Instrument Cluster	✓	✓	✓	

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LDD)	✓	•	✓	~
	1.4L(LUJ)	✓	•	✓	~
	1.8L(2H0)	✓	•	✓	~
	2.0L(LBN)	✓	•	✓	~
	2.0L(LNP)	✓	•	✓	~
	2.4L(LEA)	✓	•	✓	~
	Fuel Injector Control Module	•			
TRANSMISSION	Transmission Control Module	•	•	•	~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	✓	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Instrument Cluster	~	✓	✓	•
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	✓	•
	Front Seat Heating Control Module	~	•	~	
	Keyless Entry Control Module	~	•	~	
	Parking Assist Control Module	~	•	~	



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LUJ)	✓	•	✓	•
	1.8L(2H0)	✓	•	~	•
	2.0L(LBN)	✓	•	✓	•
	2.0L(LNP)	✓	•	~	•
	2.4L(LEA)	✓	•	✓	•
	Fuel Injector Control Module	~	•	~	
	Fuel Pump Control Module	✓	•		✓
TRANSMISSION	Transmission Control Module	~	•	~	~
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Parking Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Instrument Cluster	✓	•	✓	•
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	✓	•
	Front Seat Heating Control Module	•	•	•	
	Keyless Entry Control Module	•	•	•	
	Parking Assist Control Module	~	•	•	

Official 2012					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.8L(2H0)	✓	•	✓	✓
	2.0L(LBN)	✓	✓	✓	✓
	2.0L(LNP)	✓	•	✓	✓
	2.4L(LAF)	✓	✓	✓	✓
	Fuel Injector Control Module	•	•	•	
TRANSMISSION	Transmission Control Module	•	•	~	~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Parking Brake Control Module	•	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Instrument Cluster	✓	✓	✓	✓
	Trailer Interface Control Module	•	•	~	~
	Radio	✓	•	✓	
	Remote Heater and A/C Control Module	•	•	~	~
	Keyless Entry Control Module	•	•	•	
	Parking Assist Control Module	•	•	~	
	Steering Column Lock Control Module	~	•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.8L(2H0)	✓	•	✓	✓
	2.0L(LNP)	✓	•	✓	✓
	Fuel Injector Control Module	•	•	~	
TRANSMISSION	Transmission Control Module	•	•	~	•
CHASSIS	Electronic Brake Control Module	•	•	~	~
	Parking Brake Control Module	•	•	~	~
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	~	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	~	~	•
	Instrument Cluster	✓	•	✓	~
	Trailer Interface Control Module	~	•	~	~
	Radio	✓	•	✓	
	Remote Heater and A/C Control Module	~	•	~	~
	Keyless Entry Control Module	~	~	~	
	Parking Assist Control Module	~	~	~	
	Steering Column Lock Control Module	~	•		

Prisma 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.0L(LKL)	~	•	✓	•
	1.4L(LKJ)	✓	~	✓	•
	1.4L(LKK)	~	~	✓	•
TRANSMISSION	Transmission Control Module	•	•	•	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	•	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	•	✓	•
	Instrument Cluster	✓	•	✓	
	Radio	✓			
	Parking Assist Control Module	•	•		

Prisma 2013

Tieme 2010					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	~	•	✓	•
TRANSMISSION	Transmission Control Module	~	•	•	•
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	✓	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Instrument Cluster	✓	✓	✓	
	Radio	✓			
	Parking Assist Control Module	•	•		

S10 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LE6)	✓	✓	✓	~
	2.5L(LKH)	✓	✓	✓	✓
	2.8L(LWH)	✓	✓	✓	✓
	3.6L(LY7)	✓	✓	✓	~
RANSMISSION	Transmission Control Module	•	•	~	~
	Transfer Case Control Module	•	•	~	~
CHASSIS	Electronic Brake Control Module	•	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	✓	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	•	•		•
	Instrument Cluster	✓	✓	✓	

S10 2012~2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.4L(LE6)	✓	•	✓	•
	2.4L(LP8)	✓	•	~	•
	2.5L(LVN)	✓	•	✓	~
	2.8L(LWH)	✓	•	~	~
TRANSMISSION	Transmission Control Module	•	•	~	~
	Transfer Case Control Module	•	•	~	~
CHASSIS	Electronic Brake Control Module	•	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	✓	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	~	•		•
	Instrument Cluster	✓	✓	✓	

Sail 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LMU)	✓	•	✓	•
	1.4L(LCU)	✓	•	✓	✓
TRANSMISSION	Transmission Control Module	•	•	•	
CHASSIS	Electronic Brake Control Module	•	•	•	
BODY	Inflatable Restraint Sensing and Diagnostic Module	•	•		•

Sail 2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LMU)	~	✓	✓	•
	1.3L(LDV)	~	✓	✓	•
	1.4L(LCU)	~	✓	✓	•
TRANSMISSION	Transmission Control Module	•	•	•	



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	•	
BODY	Inflatable Restraint Sensing and Diagnostic Module	•	•		•

Sail 2012

- U.I					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.19L(LC5)	✓	•	✓	✓
	1.2L(LMU)	✓	•	✓	✓
	1.3L(LDV)	✓	•	✓	✓
	1.4L(LCU)	✓	•	✓	✓
TRANSMISSION	Transmission Control Module	•	•	•	
CHASSIS	Electronic Brake Control Module	•	•	•	
BODY	Inflatable Restraint Sensing and Diagnostic Module	•	•		•



Sail 2010~2011

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LMU)	✓	✓	✓	✓
	1.4L(LCU)	✓	✓	✓	✓
TRANSMISSION	Transmission Control Module	•	•	~	
CHASSIS	Electronic Brake Control Module	•	•	•	
BODY	Inflatable Restraint Sensing and Diagnostic Module	•	•		•

Savana 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	4.3L(LU3)	~	•	~	•
	4.8L(L20)	~	•	~	•
	5.3L(LMF)	✓	•	✓	~
	6.0L(L96)	✓	•	✓	•
	6.0L(LC8)	✓	•	✓	~
	6.6L(LGH)	~	•	~	•
	Glow Plug Control Module	~	•	~	•
TRANSMISSION	Transmission Control Module	V	•	V	•
CHASSIS	Electronic Brake Control Module	V	•	~	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	•	•	•	•
	Passenger Presence Module	•	•		
	Rollover Sensor Module	✓	•		
	Instrument Cluster	✓	•	✓	
	Chime Alarm Control Module	•		~	
	Auxiliary Heater Control Module	•	•	•	
	Parking Assist Control Module	•	•	•	
	Theft Deterrent Module	✓	•		



Silverado 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	4.3L(LV1)	✓	✓	✓	•
	4.3L(LV3)	✓	✓	✓	•
	5.3L(L83)	✓	✓	✓	•
	6.0L(L96)	✓	✓	✓	✓
	6.0L(LC8)	✓	•	✓	✓
	6.2L(L86)	✓	✓	✓	✓
	6.6L(LML)	✓	✓	✓	•
	Glow Plug Control Module	✓	✓	✓	✓
TRANSMISSION	Transmission Control Module	~	•	~	•
	Poweer Take-Off Control Module	~	•	~	~
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Trailer Brake Control Module	~	•	~	
	Suspension Control Module	~	•	~	



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	~	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	✓	•	✓	~
	Instrument Cluster	~	•	✓	
	Chime Alarm Control Module		•	~	
	Radio	✓	✓		
	Amplifier	~	•		
	HVAC Control Module	✓	•	✓	✓
	Driver Door Switch Panel Control Module	~	•	~	
	Passenger Door switch Panel Control Module	~	~	~	
	Seat Memory Control Module	~	•	~	
	Remote Control Door Lock Receiver	V	•	~	•
	Parking Assist Control Module	~	•	~	
	Theft Deterrent Module	✓	•		



Sonic 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LDC)	✓	✓	✓	✓
	1.3L(LDV)	~	•	✓	•
	1.3L(LSF)	~	•	✓	•
	1.4L(L2N)	~	•	✓	•
	1.4L(LDD)	~	•	✓	•
	1.4L(LUV)	~	•	✓	•
	1.6L(LDE)	~	•	✓	•
	1.6L(LED)	~	•	✓	•
	1.6L(LFJ)	~	•	✓	•
	1.8L(LUW)	~	•	✓	•
	1.8L(LWE)	~	•	✓	✓
	Fuel Injector Control Module	~			
	Chassis Control Module	✓	✓		•
RANSMISSION	Transmission Control Module	~	•	~	~
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Electric Power Steering Control Module	~	•		
	Steering Wheel Angle Sensor		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	~	•		•
	Instrument Cluster	✓	•	✓	
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	✓	
	Front Seat Heating Control Module	~	•	•	
	Parking Assist Control Module	~	•		



Sonic 2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LDC)	~	•	✓	✓
	1.3L(LDV)	✓	•	~	•
	1.3L(LSF)	✓	✓	✓	•
	1.4L(LDD)	✓	✓	~	✓
	1.4L(LUV)	✓	✓	✓	•
	1.6L(LDE)	✓	•	~	✓
	1.6L(LFJ)	✓	✓	✓	•
	1.8L(LUW)	✓	✓	~	✓
	1.8L(LWE)	✓	✓	✓	•
	Fuel Injector Control Module	•			
	Fuel Pump Control Module	✓	✓		•
TRANSMISSION	Transmission Control Module	•	•	~	•
CHASSIS	Electronic Brake Control Module	•	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Electric Power Steering Control Module	~	•		
	Steering Wheel Angle Sensor		•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	✓	
	Front Seat Heating Control Module	~	•	~	
	Parking Assist Control Module	~	•		



Sonic 2012

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.2L(LDC)	✓	•	✓	~
	1.3L(LDV)	✓	•	✓	✓
	1.3L(LSF)	✓	•	✓	✓
	1.4L(LDD)	✓	•	✓	✓
	1.4L(LUV)	✓	•	✓	✓
	1.6L(LDE)	✓	•	✓	✓
	1.6L(LFJ)	✓	•	✓	~
	1.8L(LUW)	✓	•	✓	✓
	Fuel Injector Control Module	~			
	Fuel Pump Control Module	✓	•		✓
RANSMISSION	Transmission Control Module	~	•	~	~
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Electric Power Steering Control Module	~	•		
	Steering Wheel Angle Sensor		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	~	•	~	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	~	•		~
	Instrument Cluster	✓	•	~	
	Radio	✓	~	✓	
	HVAC Control Module	✓	•	✓	
	Front Seat Heating Control Module	~	•	~	
	Parking Assist Control Module	~	•		

Spark 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.0L(LCP)	✓	•	✓	•
	1.0L(LFM)	✓	•	✓	•
	1.0L(LFT)	✓	•	✓	•
	1.2L(LL0)	✓	•	✓	•
	1.2L(LMU)	✓	•	✓	•
	1.2L(LKY)	✓	•	✓	•
	Fuel Injector Control Module	•			
TRANSMISSION	Transmission Control Module	•	•	~	

GM[®] Global – Page 77



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•		
	Multi-Axis Acceleration Sensor Module		•		•
	Electric Power Steering Control Mosule	~	•		
	Steering Wheel Angle Sensor		•		~
BODY	Body Control Module	✓	✓	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	~	~	~
	Instrument Cluster	✓	✓	✓	
	Passenger Presence Module	~	•		~



Spark 2013

Spark 2013 System	TYPE	DATA STREAM	READ / CLEAR FAULT	ACTIVATION	ADAPTATION
			CODE		
ENGINE	1.0L(LCP)	~	•	✓	✓
	1.0L(LEB)	✓	✓	✓	•
	1.0L(LMT)	~	•	✓	•
	1.2L(LL0)	~	•	✓	•
	1.2L(LMU)	✓	✓	✓	•
	1.2L(L2E)	~	•	✓	•
	1.2L(LKY)	✓	✓	✓	•
	Fuel Injector Control Module	~			
TRANSMISSION	Transmission Control Module	~	•	~	
CHASSIS	Electronic Brake Control Module	~	•		
	Multi-Axis Acceleration Sensor Module		•		•
	Electric Power Steering Control Mosule	~	•		
	Steering Wheel Angle Sensor		•		~
BODY	Body Control Module	~	•	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	•	,	~
	Instrument Cluster	✓	•	✓	
	Passenger Presence Module	~	•		~



Spark 2012

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.0L(LCP)	~	•	~	✓
	1.0L(LEB)	~	•	~	✓
	1.0L(LMT)	~	•	~	•
	1.2L(LMU)	~	•	~	•
	1.2L(L2E)	~	•	~	•
	Fuel Injector Control Module	~			
FRANSMISSION	Transmission Control Module	~	•	~	
CHASSIS	Electronic Brake Control Module	~	•		
	Multi-Axis Acceleration Sensor Module		•		•
	Electric Power Steering Control Mosule	~	•		
	Steering Wheel Angle Sensor		•		~
BODY	Inflatable Restraint Sensing and Diagnostic Module	~	•	,	•
	Instrument Cluster	✓	✓	✓	



Spark 2010~2011

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.0L(LCP)	~	•	~	✓
	1.0L(LEB)	✓	•	~	•
	1.0L(LMT)	~	•	~	•
	1.2L(LMU)	~	•	~	•
	Fuel Injector Control Module	~	•	~	
TRANSMISSION	Transmission Control Module	~	•	~	
CHASSIS	Electronic Brake Control Module	~	•		
	Multi-Axis Acceleration Sensor Module		•		~
	Electric Power Steering Control Mosule	~	•		
	Steering Wheel Angle Sensor		•		~
BODY	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Instrument Cluster	✓	•	✓	



Spark_EV 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
POWRETRAIN	Engine Control Module	✓	•	~	~
	Hybrid Powertrain Control Module	~	•	~	
	Drive Motor Control Module	•			
	Auxiliary Transmission Fluid Pump	•			
CHASSIS	Electronic Brake Control Module	•	•	~	•
	Parking Brake Control Module	•	•	~	~
	Power Steering Control Module	~	•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	~	✓
	Pedestrian Alert Sound Control Module	•	•		
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	✓	✓	✓
	Radio	✓	~	✓	
	HVAC Control Module	✓	✓	✓	✓
	Coolant Heater Control Module		•		
	Keyless Entry Control Module	•	•		
	Battery Charger Control Module	•			
	DC Charging Control Module	•			
	Hybrid Powertrain Control Module 2	•	•	~	•
	Battery Energy Control Module	~			



Spin 2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.3L(LDV)	✓	•	✓	✓
	1.3L(LSF)	✓	✓	✓	~
	1.8L(LJ1)	✓	✓	✓	•
	1.8L(LMD)	✓	✓	✓	~
TRANSMISSION	Transmission Control Module	~	•	~	~
CHASSIS	Electronic Brake Control Module	~	•	~	~
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		~
BODY	Body Control Module	✓	•	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Instrument Cluster	✓	✓	✓	
	Radio	✓	•	✓	
	HVAC Control Module	✓	✓	✓	
	Parking Assist Control Module	~	~		



SS 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	✓	✓	~	✓
	Chassis Control Module	✓	•		•
TRANSMISSION	Transmission Control Module	•	•	~	~
CHASSIS	Electronic Brake Control Module	•	•	~	~
	Parking Brake Control Module	•	•	~	•
	Power Steering Control Module	•	•		~
	Steering Wheel Angle Sensor Module		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	~	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•		~
	Instrument Cluster	✓	✓	✓	
	Radio Controls	✓	✓	✓	
	HVAC Controls	✓	✓	✓	
	Headlamp Control Module	✓	•	~	✓
	Trailer Interface Control Module	•	•	~	
	Radio	✓	•	~	
	HVAC Control Module	✓	•	✓	✓
	Keyless Entry Control Module	•	•	~	
	Right Side Object Detection Control Module		•	~	
	Left Side Object Detection Control Module		•	~	
	Parking Assist Control Module	•	•	~	



Suburban & Tahoe 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	✓	•	✓	•
	Chassis Control Module	✓	✓	✓	•
TRANSMISSION	Transmission Control Module	✓	✓	✓	•
	Transfer case Control Module	✓	✓	✓	•
CHASSIS	Electronic Brake Control Module	✓	✓	✓	•
	Parking Brake Control Module	✓	✓	✓	✓
	Suspension Control Module	✓	✓	✓	



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	✓	~	✓
	Auxiliary Body Control Module	✓	✓	~	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	~		•
	Passenger Presence Module	✓	✓		
	Instrument Cluster	✓	✓	~	
	Radio	✓	✓	✓	
	Amplifier	✓	✓		
	HVAC Control Module	✓	✓	✓	✓
	Driver Door switch Panel Control Module	~	•	~	
	Passenger Door switch Panel Control Module	~	•	~	
	Liftgate Control Module	✓	✓		✓
	Seat Memory Control Module	✓	✓	~	
M A R C	Rear Seat Heating Control Module	~	•	~	
	Assit Step Control Module	✓	✓	~	
	Right Side Object Detection Control Module	•	•	~	
	Left Side Object Detection Control Module	~	•	~	



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Remote Control Door Lock Receiver	•	•	•	•
	Parking Assist Control Module	✓	✓	✓	
	Theft Deterrent Module	✓	•		

Tavera 2011~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	✓	✓	✓	

Tracker 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LUJ)	✓	•	✓	✓
	1.4L(LUV)	~	✓	✓	✓
	1.6L(LDE)	✓	✓	✓	✓
	1.7L(LUD)	~	✓	✓	✓
	1.8L(2H0)	✓	✓	✓	✓
	1.8L(LFH)	~	✓	✓	✓
	Chassis Control Module	✓	✓		✓
TRANSMISSION	Transmission Control Module	•	•	~	•
	Rear Differential Clutch Control Module	•	•		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		•
	Power Steering Control Module	~	•		
BODY	Body Control Module	~	•	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	~
	Passenger Presence Module	~	•		•
	Instrument Cluster	~	~	✓	
	Radio	~			
	HVAC Control Module	~	✓	✓	
	Front Seat Heating Control Module	~	~	~	
	Parking Assist Control Module	~	•	~	



Tracker 2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LUJ)	✓	✓	✓	•
	1.6L(LDE)	✓	•	✓	✓
	1.7L(LUD)	✓	•	✓	•
	1.8L(2H0)	✓	•	✓	•
	1.8L(LFH)	✓	•	✓	•
TRANSMISSION	Transmission Control Module	~	•	~	•
	Rear Differential Clutch Control Module	•	•		•
CHASSIS	Electronic Brake Control Module	~	•	~	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
	Power Steering Control Module	•	•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	~
	Passenger Presence Module	~	•		•
	Instrument Cluster	✓	•	✓	
	Radio	✓			
	HVAC Control Module	✓	•	✓	
	Front Seat Heating Control Module	~	~	V	
	Parking Assist Control Module	~	•	~	

Trailblazer 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.5L(LKH)	•	•	✓	✓
	2.8L(LWN)	✓	•	✓	✓
	3.6L(LY7)	•	•	✓	•
TRANSMISSION	Transmission Control Module	•	•	~	~
	Transfer Case Control Module	•	•	•	~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•		•
	Instrument Cluster	✓	•	✓	
	Trailer Interface Control Module	•	•	•	
	Park Assist System Data	✓	•	✓	

Trailblazer 2013

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	2.5L(LVN)	•	•	✓	~
	2.8L(LWH)	✓	✓	✓	✓
	3.6L(LFX)	•	✓	✓	•
	3.6L(LY7)	✓	✓	✓	•
TRANSMISSION	Transmission Control Module	•	•	•	•
	Transfer Case Control Module	•	•	~	V



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
CHASSIS	Electronic Brake Control Module	•	•	•	•
	Multi-Axis Acceleration Sensor Module		•		•
	Steering Wheel Angle Sensor		•		•
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•		•
	Instrument Cluster	✓	•	✓	
	Trailer Interface Control Module	•	•	•	
	Park Assist System Data	✓	•	✓	

Traverse 2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	✓	✓	✓	•
	Chassis Control Module	✓	✓		•
TRANSMISSION	Transmission Control Module	•	•	•	•
	Rear Differential Clutch Control Module	•	•	•	
CHASSIS	Electronic Brake Control Module	•	•	•	•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	✓
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	
	Radio	✓	•	✓	
	HVAC Control Module	✓	•	✓	✓
	Driver Door switch Panel Control Module	•	•	✓	
	Passenger Door switch Panel Control Module	•	•	~	
	Liftgate Control Module	✓	•		✓
	Seat Memory Control Module	•	•	~	
	Right Side Object Detection Control Module		•	~	
	Left Side Object Detection Control Module		•	~	
	Remote Control Door Lock Receiver	~	~	~	~
	Parking Assist Control Module	~	•	~	
	Theft Deterrent Module	✓	•		



Trax 2013~2014

11ax 2013~2014					
SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	1.4L(LUJ)	✓	•	✓	•
	1.4L(LUV)	✓	✓	~	•
	1.6L(LDE)	✓	•	✓	•
	1.7L(LUD)	✓	•	~	•
	1.8L(2H0)	✓	•	✓	•
	Fuel Injector Control Module	•			
TRANSMISSION	Transmission Control Module	•	•	~	~
	Rear Differential Clutch Control Module	•	•		~
CHASSIS	Electronic Brake Control Module	•	•	~	•
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		•
	Power Steering Control Module	•	•		



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	~	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	
	Radio	✓			
	HVAC Control Module	✓	•	✓	
	Front Seat Heating Control Module	~	•	~	
	Parking Assist Control Module	~	•	~	



Volt 2013~2014

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	~	•	~	✓
	Fuel Pump Control Module	~	•		✓
	Hybrid Powertrain Control Module	~	•	v	
FRANSMISSION	Transmission Control Module	~	•	~	
	Drive Motor Control Module 1	~			
	Drive Motor Control Module 2	~			
	Auxiliary Transmission Fluid Pump	~			
CHASSIS	Electronic Brake Control Module	V	•	V	•
	Parking Brake Control Module	V	•	V	~
	Multi-Axis Acceleration Sensor Module		•		~
	Steering Wheel Angle Sensor		•		~



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	~
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	~	~		•
	Instrument Cluster	~	✓	~	~
	Radio	✓	✓	~	
	HVAC Control Module	~	✓	~	~
	Coolant Heater Control Module		~		
	Keyless Entry Control Module		~		
	Parking Assist Control Module	~	•	~	
	Steering Column Lock Control Module	•	~		
	Battery Charger Control Module	~			
	Hybrid Powertrain Control Module 2	~	~		•
	Battery Energy Control Module	~			
	Front Seat Heating Control Module	~	~	~	



Volt 2012

SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
ENGINE	Engine Control Module	✓	~	✓	•
	Fuel Pump Control Module	✓	✓		~
	Hybrid Powertrain Control Module	~	•	~	
RANSMISSION	Transmission Control Module	~	•	V	
	Drive Motor Control Module 1	~			
	Drive Motor Control Module 2	~			
	Auxiliary Transmission Fluid Pump	~			
CHASSIS	Electronic Brake Control Module	~	~	~	•
	Parking Brake Control Module	~	•	✓	•
	Multi-Axis Acceleration Sensor Module		~		•
	Steering Wheel Angle Sensor		~		•



SYSTEM	TYPE	DATA STREAM	READ / CLEAR FAULT CODE	ACTIVATION	ADAPTATION
BODY	Body Control Module	✓	•	✓	•
	Inflatable Restraint Sensing and Diagnostic Module	•	•	~	•
	Passenger Presence Module	•	•		•
	Instrument Cluster	✓	•	✓	•
	Radio	✓	•	✓	
	Remote Heater and A/C Control Module	•	•	~	•
	Coolant Heater Control Module		•		
	Keyless Entry Control Module		•		
	Parking Assist Control Module	•	•	•	
	Steering Column Lock Control Module	•	•		
	Battery Charger Control Module	•			
	Hybrid Powertrain Control Module 2	•	•		•
	Battery Energy Control Module	•			

The information contained herein is the exclusive property of Autoland Scientech® and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Autoland Scientech®. Autoland Scientech® reserve the right to make any change without notice. All trademarks belong to the owners.