



- **RELEASE 171: SPECIAL FUNCTIONS**



Via Modena 34,
Correggio Italy
Tel +39 0522747411
www.tecnomotor.it

PARTICULATE FILTER REGENERATION

KIA DIESEL RIO (YB-SC) 1.4 CRDI (57 kw) (D4FC) - - - ECM (CAN) (2017-)

KIA DIESEL RIO (YB-SC) 1.4 CRDI 90CV (66 kw) (D4FC) - - - ECM (CAN) (2017-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

PARTICULATE FILTER REGENERATION

LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (110 kw) (2AD-FTV) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (130 kw) (2AD-FHV) - - - ENGINE #AUTOCONF (2005-2013)

TOYOTA DIESEL AVENSIS SEDAN (T27) 1.6 D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AVENSIS SEDAN (T27) 2.0 D-4D (105 kw) (2WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AVENSIS SPORTWAGON (T27) 1.6 D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AVENSIS SPORTWAGON (T27) 2.0 D-4D (105 kw) (2WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AYGO (B10) 1.4 HDI (40 kw) (2WZ-TV) - - - ENGINE #AUTOCONF (2005-2014)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 100 (65 kw) (2KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 150 (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 150 (75 kw) (2KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (106 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (65 kw) (5L) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (80 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-TQ) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-UL) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-UP) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (132 kw) (N04C-UQ) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (85 kw) (N04C-UM) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D 4WD (110 kw) (N04C-UL) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D 4WD (110 kw) (N04C-UP) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.6 D4D (96 kw) (S05C) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL ETIOS (NUK1-NGK1) 1.4 D-4D (50 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)

TOYOTA DIESEL ETIOS SEDAN (NGK1) 1.4 D-4D (50 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)

TOYOTA DIESEL HIACE FURG. (V TRH2-KDH2) 3.0 D (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL HIACE FURG. (V TRH2-KDH2) 3.0 D (106 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL HILUX PICK UP (III KUN) 2.8 D (125 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL HILUX PICK UP (III KUN) 2.8 D 4WD (128 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL IQ (GJ1-AJ) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL LAND CRUISER (J15) 2.8 D-4D (130 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2010-)

TOYOTA DIESEL URBAN CRUISER (NCP) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL URBAN CRUISER (NCP) 1.4 D-4D 4X4 (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL VERSO (AUR2-ZGR2) 1.6 D-4D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL VERSO MULTISPACE (II) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-2016)

TOYOTA DIESEL YARIS (III P13) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)

INJECTORS CODING

KIA DIESEL RIO (YB-SC) 1.4 CRDI (57 kw) (D4FC) - - - ECM (CAN) (2017-)

KIA DIESEL RIO (YB-SC) 1.4 CRDI 90CV (66 kw) (D4FC) - - - ECM (CAN) (2017-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

INJECTORS CODING

LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (110 kw) (2AD-FTV) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (130 kw) (2AD-FHV) - - - ENGINE #AUTOCONF (2005-2013)

TOYOTA DIESEL AVENSIS SEDAN (T27) 1.6 D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AVENSIS SEDAN (T27) 2.0 D-4D (105 kw) (2WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AVENSIS SPORTWAGON (T27) 1.6 D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AVENSIS SPORTWAGON (T27) 2.0 D-4D (105 kw) (2WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL AYGO (B10) 1.4 HDI (40 kw) (2WZ-TV) - - - ENGINE #AUTOCONF (2005-2014)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 100 (65 kw) (2KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 150 (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 150 (75 kw) (2KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (106 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (65 kw) (5L) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (80 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-TQ) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-UL) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-UP) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (132 kw) (N04C-UQ) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (85 kw) (N04C-UM) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D 4WD (110 kw) (N04C-UL) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D 4WD (110 kw) (N04C-UP) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.6 D4D (96 kw) (S05C) - - - ENGINE #AUTOCONF (2006-)

TOYOTA DIESEL ETIOS (NUK1-NGK1) 1.4 D-4D (50 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)

TOYOTA DIESEL ETIOS SEDAN (NGK1) 1.4 D-4D (50 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)

TOYOTA DIESEL HIACE FURG. (V TRH2-KDH2) 3.0 D (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL HIACE FURG. (V TRH2-KDH2) 3.0 D (106 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL HILUX PICK UP (III KUN) 2.8 D (125 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL HILUX PICK UP (III KUN) 2.8 D 4WD (128 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2005-)

TOYOTA DIESEL IQ (GJ1-AJ) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL LAND CRUISER (J15) 2.8 D-4D (130 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2010-)

TOYOTA DIESEL URBAN CRUISER (NCP) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL URBAN CRUISER (NCP) 1.4 D-4D 4X4 (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL VERSO (AUR2-ZGR2) 1.6 D-4D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)

TOYOTA DIESEL VERSO MULTISPACE (II) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-2016)

TOYOTA DIESEL YARIS (III P13) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)

ESP-STEERING ANGLE ADJUSTMENT

HYUNDAI I10 (IA) - - - MDPS (CAN) (2013-)

TPMS CODING

HYUNDAI TUCSON - - - TPMS (CAN) (2015-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

PADS REPLACEMENT

LEXUS CT (ZWA) - - - EPB #AUTOCONF (2010-)
LEXUS GS (GRL1-GWL1) - - - EPB #AUTOCONF (2012-)
LEXUS GS (GWS-GRS-UZS) - - - EPB #AUTOCONF (2005-2011)
LEXUS IS (GSE2-ALE2-USE2) - - - EPB #AUTOCONF (2005-2013)
LEXUS IS (GSE3-AVE3) - - - EPB #AUTOCONF (2013-)
LEXUS IS CABRIO (GSE2) - - - EPB #AUTOCONF (2009-)
LEXUS LFA - - - EPB #AUTOCONF (2010-2012)
LEXUS LS (UVF4-USF4) - - - EPB #AUTOCONF (2006-)
LEXUS LX (URJ201) - - - EPB #AUTOCONF (2007-)
LEXUS NX (ZGZ1-AYZ1-AGZ1) - - - EPB #AUTOCONF (2014-)
LEXUS RC - - - EPB #AUTOCONF (2014-)
LEXUS RX (AGL2-GGL2) - - - EPB #AUTOCONF (2015-)
LEXUS RX (GYL1-GGL1-AGL1) - - - EPB #AUTOCONF (2008-2015)
TOYOTA AURIS (E18) - - - EPB #AUTOCONF (2012-)
TOYOTA AURIS (ZE15-RE15) - - - EPB #AUTOCONF (2007-2012)
TOYOTA AURIS STATION WAGON (NDE18-ZRE18) - - - EPB #AUTOCONF (2013-)
TOYOTA AURIS VAN (ZRE18-NZE18) - - - EPB #AUTOCONF (2013-)
TOYOTA AURIS VAN - - - EPB #AUTOCONF (2007-2013)
TOYOTA AVENSIS SEDAN (T27) - - - EPB #AUTOCONF (2009-)
TOYOTA AVENSIS SPORTWAGON (T27) - - - EPB #AUTOCONF (2009-)
TOYOTA C-HR (NGX1-NGX5-ZYX1) - - - EPB #AUTOCONF (2016-)
TOYOTA PRIUS (W5) - - - EPB #AUTOCONF (2016-)
TOYOTA PRIUS (ZVW30) - - - EPB #AUTOCONF (2009-)
TOYOTA PRIUS C (NHP10) - - - EPB #AUTOCONF (2012-)
TOYOTA PRIUS PHV (W3) - - - EPB #AUTOCONF (2012-)
TOYOTA PRIUS PHV (W52) - - - EPB #AUTOCONF (2016-)
TOYOTA PRIUS PLUS (ZVW) - - - EPB #AUTOCONF (2012-)
TOYOTA RAV 4 (ALA4) - - - EPB #AUTOCONF (2012-)
TOYOTA RAV 4 (III ZSA-) - - - EPB #AUTOCONF (2005-2013)

BRAKES BLEEDING

HYUNDAI I10 (IA) - - - ABS (CAN) (2013-)

Lambda probe replacement (for equipment with Lambda only) - ENGINE

Rail Pressure sensor replacement - ENGINE

To perform after the replacement of the mass air flow sensor - ENGINE

Differential pressure sensor replacement - ENGINE

SCV sensor replacement (swirl Control Valve) - ENGINE

Motor-driven throttle replacement - ENGINE

EGR valve replacement - ENGINE

APS module replacement - ENGINE

Replacing DPF particulate filter - ENGINE

Catalytic converter+DPF replacement - ENGINE

KIA DIESEL RIO (YB-SC) 1.4 CRDI (57 kw) (D4FC) - - - ECM (CAN) (2017-)

KIA DIESEL RIO (YB-SC) 1.4 CRDI 90CV (66 kw) (D4FC) - - - ECM (CAN) (2017-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

Write VIN - ENGINE

Learning value reset - ENGINE

Throttle learning memorization - ENGINE

LEXUS GASOLINE ES (AVV6) 250 (135 kw) (2AR-FE) - - - ENGINE #AUTOCONF (2012-)

LEXUS GASOLINE ES (AVV6) 350 (204 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2012-)

LEXUS GASOLINE GS (GRL1-GWL1) 250 (158 kw) (4GR-FSE) - - - ENGINE #AUTOCONF (2012-)

LEXUS GASOLINE GS (GRL1-GWL1) 350 (233 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2012-)

LEXUS GASOLINE GS (GRL1-GWL1) F (348 kw) (2UR-GSE) - - - ENGINE #AUTOCONF (2012-)

LEXUS GASOLINE GS (GRL1-GWL1) F (351 kw) (2UR-GSE) - - - ENGINE #AUTOCONF (2012-)

LEXUS GASOLINE GS (GRL1-GWL1) GS 250 (154 kw) (4GR-FSE) - - - ENGINE #AUTOCONF (2012-)

LEXUS GASOLINE GS (GWS-GRS-UZS) 3.0 (170 kw) (3GR-FE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 3.0 (170 kw) (3GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 300 (183 kw) (3GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 300 AWD (183 kw) (3GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 350 (226 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 350 (232 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 350 AWD (226 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 350 AWD (232 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 4.3 VVTI (221 kw) (3UZ-FE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 430 (208 kw) (3UZ-FE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 430 (216 kw) (3UZ-FE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 460 (255 kw) (1UR-FE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 460 (255 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2005-2011)

LEXUS GASOLINE GX (URJ15) 460 (218 kw) (1UR-FE) - - - ENGINE #AUTOCONF (2010-)

LEXUS GASOLINE GX (URJ15) 460 (225 kw) (1UR-FE) - - - ENGINE #AUTOCONF (2010-)

LEXUS GASOLINE IS (GSE2-ALE2-USE2) 250 (153 kw) (4GR-FSE) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS GASOLINE IS (GSE2-ALE2-USE2) 250 AWD (152 kw) (4GR-FSE) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS GASOLINE IS (GSE2-ALE2-USE2) 350 (228 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS GASOLINE IS (GSE2-ALE2-USE2) 350 (234 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS GASOLINE IS (GSE2-ALE2-USE2) 350 AWD (228 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS GASOLINE IS (GSE2-ALE2-USE2) IS F (311 kw) (2UR-GSE) - - - ENGINE #AUTOCONF (2005-2013)

LEXUS GASOLINE IS (GSE3-AVE3) 250 (153 kw) (4GR-FSE) - - - ENGINE #AUTOCONF (2013-)
 LEXUS GASOLINE IS CABRIO (GSE2) 250 (153 kw) (4GR-FSE) - - - ENGINE #AUTOCONF (2009-)
 LEXUS GASOLINE IS CABRIO (GSE2) 300 (170 kw) (3GR-FE) - - - ENGINE #AUTOCONF (2009-)
 LEXUS GASOLINE IS CABRIO (GSE2) 350 (228 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2009-)
 LEXUS GASOLINE IS CABRIO (GSE2) 350 (234 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2009-)
 LEXUS GASOLINE LFA 4.8 (412 kw) (1LR-GUE) - - - ENGINE #AUTOCONF (2010-2012)
 LEXUS GASOLINE LFA 4.8 (420 kw) (1LR-GUE) - - - ENGINE #AUTOCONF (2010-2012)
 LEXUS GASOLINE LS (UVF4-USF4) 460 (255 kw) (1UR-FE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 (272 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 (280 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 (285 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 (288 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 AWD (270 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 AWD (272 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 AWD (280 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 460 AWD (288 kw) (1UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LS (UVF4-USF4) 600 H (290 kw) (2UR-FSE) - - - ENGINE #AUTOCONF (2006-)
 LEXUS GASOLINE LX (URJ201) 570 (270 kw) (3UR-FE) - - - ENGINE #AUTOCONF (2007-)
 LEXUS GASOLINE NX (ZGZ1-AYZ1-AGZ1) 200 (110 kw) (3ZR-FAE) - - - ENGINE #AUTOCONF (2014-)
 LEXUS GASOLINE NX (ZGZ1-AYZ1-AGZ1) 200 AWD (110 kw) (3ZR-FAE) - - - ENGINE #AUTOCONF (2014-)
 LEXUS GASOLINE NX (ZGZ1-AYZ1-AGZ1) 200T (175 kw) (8AR-FTS) - - - ENGINE #AUTOCONF (2014-)
 LEXUS GASOLINE RC 200T (180 kw) (8AR-FTS) - - - ENGINE #AUTOCONF (2014-)
 LEXUS GASOLINE RC 350 (234 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2014-)
 LEXUS GASOLINE RC F (348 kw) (2UR-GSE) - - - ENGINE #AUTOCONF (2014-)
 LEXUS GASOLINE RC F (351 kw) (2UR-GSE) - - - ENGINE #AUTOCONF (2014-)
 LEXUS GASOLINE RX (AGL2-GGL2) 200T (175 kw) (8AR-FTS) - - - ENGINE #AUTOCONF (2015-)
 LEXUS GASOLINE RX (AGL2-GGL2) 200T AWD (175 kw) (8AR-FTS) - - - ENGINE #AUTOCONF (2015-)
 LEXUS GASOLINE RX (AGL2-GGL2) 350 (220 kw) (2GR-FKS) - - - ENGINE #AUTOCONF (2015-)
 LEXUS GASOLINE RX (AGL2-GGL2) 350 4WD (220 kw) (2GR-FKS) - - - ENGINE #AUTOCONF (2015-)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 270 (138 kw) (1AR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 3.5 AWD (183 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (201 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (202 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (204 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (204 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (205 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (201 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (202 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (204 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (204 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (205 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS HYBRID CT (ZWA) 200H (73 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2010-)
 LEXUS HYBRID CT (ZWA) 200H (73 kw) (5ZR-FXE) - - - ENGINE #AUTOCONF (2010-)
 LEXUS HYBRID ES (AVV6) 300H (118 kw) (2AR-FXE) - - - ENGINE #AUTOCONF (2012-)
 LEXUS HYBRID GS (GRL1-GWL1) 450H (217 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2012-)
 LEXUS HYBRID GS (GRL1-GWL1) GS 300H (133 kw) (2AR-FSE) - - - ENGINE #AUTOCONF (2012-)
 LEXUS HYBRID GS (GRL1-GWL1) GS 450H (215 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2012-)

LEXUS HYBRID GS (GWS-GRS-UZS) 450 H (218 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)
 LEXUS HYBRID GS (GWS-GRS-UZS) 450 H (254 kw) (2GR-FSE) - - - ENGINE #AUTOCONF (2005-2011)
 LEXUS HYBRID IS (GSE3-AVE3) 300H (131 kw) (2AR-FSE) - - - ENGINE #AUTOCONF (2013-)
 LEXUS HYBRID NX (ZGZ1-AYZ1-AGZ1) 300H (114 kw) (2AR-FXE) - - - ENGINE #AUTOCONF (2014-)
 LEXUS HYBRID RC 300H (131 kw) (2AR-FSE) - - - ENGINE #AUTOCONF (2014-)
 LEXUS HYBRID RX (AGL2-GGL2) 450H (230 kw) (2GR-FXS) - - - ENGINE #AUTOCONF (2015-)
 LEXUS HYBRID RX (AGL2-GGL2) 450H AWD (193 kw) (2GR-FXS) - - - ENGINE #AUTOCONF (2015-)
 LEXUS HYBRID RX (AGL2-GGL2) 450H AWD (230 kw) (2GR-FXS) - - - ENGINE #AUTOCONF (2015-)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 350H (220 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 350H AWD (220 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 450H (183 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2008-2015)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 450H AWD (183 kw) (2GR-FXE) - - - ENGINE #AUTOCONF (2008-2015)
 TOYOTA BIFUEL COROLLA SEDAN (E18) 1.6 16V VVT-I (91 kw) (1ZR-FE) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA BIFUEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.1 LPG (85 kw) (1BZ-FPE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 2.7 (116 kw) (2TR-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 2.7 4WD (117 kw) (2TR-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 4.0 (201 kw) (1GR-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 4.0 4WD (201 kw) (1GR-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE AURIS (E18) 1.2 (85 kw) (8NR-FTS) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE AURIS (E18) 1.5 (80 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE AURIS (E18) 1.5 4WD (77 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE AURIS (E18) 1.8 (103 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE AURIS (E18) 1.8 (103 kw) (2ZR-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE AURIS (E18) 1.8 (106 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE AURIS (ZE15-RE15) 1.5 (81 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2007-2012)
 TOYOTA GASOLINE AURIS (ZE15-RE15) 1.5 4WD (77 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2007-2012)
 TOYOTA GASOLINE AURIS (ZE15-RE15) 1.8 (108 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2007-2012)
 TOYOTA GASOLINE AURIS (ZE15-RE15) 1.8 4WD (94 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2007-2012)
 TOYOTA GASOLINE AURIS (ZE15-RE15) 1.8 VVT-I (108 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2007-2012)
 TOYOTA GASOLINE AURIS (ZE15-RE15) 1.8 VVTI (100 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2007-2012)
 TOYOTA GASOLINE AURIS (ZE15-RE15) 1.8 VVTI (100 kw) (2ZR-FE) - - - ENGINE #AUTOCONF (2007-2012)
 TOYOTA GASOLINE AURIS STATION WAGON (NDE18-ZRE18) 1.2 (85 kw) (8NR-FTS) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA GASOLINE AVENSIS SEDAN (T27) 2.0 (100 kw) (1AZ-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE AVENSIS SEDAN (T27) 2.0 (112 kw) (3ZR-FAE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE AVENSIS SPORTWAGON (T27) 2.0 (112 kw) (3ZR-FAE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE AYGO (MY2014) 1.2 (60 kw) (1PP) - - - ENGINE #AUTOCONF (2014-)
 TOYOTA GASOLINE C-HR (NGX1-NGX5-ZYX1) 1.2 (85 kw) (8NR-FTS) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA GASOLINE C-HR (NGX1-NGX5-ZYX1) 1.2 4WD (85 kw) (8NR-FTS) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 2.0 (109 kw) (1AZ-FE) - - - ENGINE #AUTOCONF (2011-)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 2.5 (133 kw) (2AR-FE) - - - ENGINE #AUTOCONF (2011-)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 3.5 (204 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2011-)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 3.5 V6 (183 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2011-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.6 VVT-I (79 kw) (3ZZ-FNE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.6 VVT-I (91 kw) (1ZR-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.6 VVT-I (97 kw) (1ZR-FAE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 (106 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 4WD (98 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2006-)

TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVT-I (108 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVTI (103 kw) (2ZR-FBE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVTI (103 kw) (2ZR-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVTL-I (100 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVTL-I (100 kw) (2ZR-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.3 (73 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.6 (97 kw) (1ZR-FAE) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.6 16V VVT-I (91 kw) (1ZR-FE) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.8 (103 kw) (2ZR-FE) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.8 16V VVT-I (103 kw) (2ZR-FE) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (NZE16) 1.3 (70 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA SEDAN (NZE16) 1.5 (80 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA SEDAN (NZE16) 1.5 4WD (76 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA STATION WAGON (NKE16-NZE16) 1.5 (80 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA STATION WAGON (NKE16-NZE16) 1.5 4WD (76 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA STATION WAGON (NKE16-NZE16) 1.8 (103 kw) (2ZR-FAE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 2.7 (109 kw) (2TR-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE ETIOS (NUK1-NGK1) 1.2 (59 kw) (3NR-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE GT86 COUPÉ (ZN6) 2.0 (147 kw) (FA20) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE GT86 COUPÉ (ZN6) 2.0 (147 kw) (FA20D) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE GT86 COUPÉ (ZN6) 2.0 (149 kw) (FA20D) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE HIACE FURG. (V TRH2-KDH2) 2.7 VVTI (111 kw) (2TR-FE) - - - ENGINE #AUTOCONF (2005-)
 TOYOTA GASOLINE HILUX PICK UP (III KUN) 2.0 (108 kw) (1AZ-FSE) - - - ENGINE #AUTOCONF (2005-)
 TOYOTA GASOLINE IQ (GJ1-AJ) 1.3 (72 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE IQ (GJ1-AJ) 1.3 VVT-I (74 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE LAND CRUISER (J15) 2.7 (120 kw) (2TR-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE LAND CRUISER (J15) 4.0 (207 kw) (1GR-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE LAND CRUISER (J15) 4.0 V6 VVT-I (207 kw) (1GR-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE LAND CRUISER (J20) 4.6 V8 (234 kw) (1UR-FE) - - - ENGINE #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (J20) 5.7 V8 (268 kw) (3UR-FE) - - - ENGINE #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (J20) 5.7 V8 (284 kw) (3UR-FE) - - - ENGINE #AUTOCONF (2008-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 2.4 (125 kw) (2AZ-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 3.5 (200 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 3.5 (206 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 3.5 4WD (206 kw) (2GR-FE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA GASOLINE RAV 4 (ALA4) 2.5 VVT-I 4WD (132 kw) (2AR-FE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA GASOLINE URBAN CRUISER (NCP) 1.5 VVTI (80 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE URBAN CRUISER (NCP) 1.5 VVTI 4WD (76 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2009-)
 TOYOTA GASOLINE VERSO MULTISPACE (II) 1.5 (80 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2010-2016)
 TOYOTA GASOLINE VERSO MULTISPACE (II) 1.5 4WD (76 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2010-2016)
 TOYOTA GASOLINE YARIS (III P13) 1.3 (70 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (III P13) 1.3 4WD (70 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (III P13) 1.3 VVT-I (63 kw) (2NZ-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (III P13) 1.33 VVT-I (73 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (III P13) 1.33 VVT-I (73 kw) (1NR-FKE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (III P13) 1.5 (76 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2010-)

TOYOTA GASOLINE YARIS (III P13) 1.5 (79 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (III P13) 1.5 (80 kw) (1NZ-FE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (III P13) 1.5 (82 kw) (2NR-FKE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA GASOLINE YARIS (IV NCP15) 1.0 (49 kw) (1KR-FE) - - - ENGINE #AUTOCONF (2015-)
 TOYOTA GASOLINE YARIS (IV NCP15) 1.2 (63 kw) (3NR-FE) - - - ENGINE #AUTOCONF (2015-)
 TOYOTA GASOLINE YARIS (IV NCP15) 1.3 (66 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2015-)
 TOYOTA GASOLINE YARIS (IV NCP15) 1.3 (73 kw) (1NR-FE) - - - ENGINE #AUTOCONF (2015-)
 TOYOTA GASOLINE YARIS (IV NCP15) 1.5 HYBRID (80 kw) (1NZ-FXE) - - - ENGINE #AUTOCONF (2015-)
 TOYOTA HYBRID AURIS (E18) 1.8 HSD (73 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA HYBRID AURIS (ZE15-RE15) 1.8 HYBRID (73 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2007-2012)

TOYOTA HYBRID AURIS STATION WAGON (NDE18-ZRE18) 1.8 HYBRID (73 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2013-)
 TOYOTA HYBRID C-HR (NGX1-NGX5-ZYX1) 1.8 HYBRID (72 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA HYBRID C-HR (NGX1-NGX5-ZYX1) 1.8 HYBRID (90 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA HYBRID CAMRY SEDAN (XV5) 2.5 HYBRID (118 kw) (2AR-FXE) - - - ENGINE #AUTOCONF (2011-)
 TOYOTA HYBRID CAMRY SEDAN (XV5) 2.5 HYBRID (118 kw) (2JM) - - - ENGINE #AUTOCONF (2011-)
 TOYOTA HYBRID PREVIA (III ACR5-GSR5) 2.4 HYBRID (110 kw) (2AZ-FXE) - - - ENGINE #AUTOCONF (2006-)
 TOYOTA HYBRID PRIUS (W5) 1.8 (72 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA HYBRID PRIUS (W5) 1.8 HYBRID (90 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA HYBRID PRIUS (W5) 1.8 HYBRID E-FOUR 4WD (72 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA HYBRID PRIUS C (NHP10) 1.5 HYBRID (54 kw) (1NZ-FXE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA HYBRID PRIUS C (NHP10) 1.5 HYBRID (74 kw) (1NZ-FXE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA HYBRID PRIUS PHV (W3) 1.8 PLUG-IN HYBRID (73 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA HYBRID PRIUS PHV (W52) 1.8 PLUG-IN HYBRID (72 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2016-)
 TOYOTA HYBRID PRIUS PLUS (ZVW) 1.8 (73 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA HYBRID PRIUS PLUS (ZVW) 1.8 HYBRID (100 kw) (2ZR-FXE) - - - ENGINE #AUTOCONF (2012-)
 TOYOTA HYBRID YARIS (III P13) 1.5 HYBRID (55 kw) (1NZ-FXE) - - - ENGINE #AUTOCONF (2010-)
 TOYOTA HYBRID YARIS (III P13) HYBRID (55 kw) (1NZ-FXE) - - - ENGINE #AUTOCONF (2010-)

Brake pedal calibration - ENGINE

Clutch actuator learning - ENGINE

Reset the values acknowl. by the A/C system - ENGINE

Self-learning throttle body - ENGINE

TLC misfire reset - ENGINE

Self-adaptive parameter reset - ENGINE

Camshaft Adaption Reset - ENGINE

Restore adaptives memories after oil change - ENGINE

Restore adaptives memories after block change - ENGINE

Restore adaptives memories air/fuel - ENGINE

Restore memory VVA incorrect freeze request - ENGINE

Restore accelerator pedal adaptives - ENGINE

FIAT GASOLINE 124 SPIDER (MY2016) 1.4 MULTIAIR (103 kw) (55253268) MARELLI 8GMK (CAN) (2016-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

Compression test - ENGINE

Fuel injection pump learning - ENGINE

A/F sensor compensation reset - ENGINE

Learning value reset for starting time compensation - ENGINE

Nox catalytic converter data reset - ENGINE

Pilot quantity memorization - ENGINE

Pilot quantity memorization (Detail) - ENGINE

Injection adjustment value reset - ENGINE

LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (110 kw) (2AD-FTV) - - - ENGINE #AUTOCONF (2005-2013)
LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (130 kw) (2AD-FHV) - - - ENGINE #AUTOCONF (2005-2013)
TOYOTA DIESEL AVENSIS SEDAN (T27) 1.6 D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL AVENSIS SEDAN (T27) 2.0 D-4D (105 kw) (2WW) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL AVENSIS SPORTWAGON (T27) 1.6 D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL AVENSIS SPORTWAGON (T27) 2.0 D-4D (105 kw) (2WW) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL AYGO (B10) 1.4 HDI (40 kw) (2WZ-TV) - - - ENGINE #AUTOCONF (2005-2014)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 100 (65 kw) (2KD-FTV) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 150 (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 150 (75 kw) (2KD-FTV) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (106 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (65 kw) (5L) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 3.0 D4D (80 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-TQ) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-UL) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (110 kw) (N04C-UP) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (132 kw) (N04C-UQ) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D (85 kw) (N04C-UM) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D 4WD (110 kw) (N04C-UL) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.0 D4D 4WD (110 kw) (N04C-UP) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) 4.6 D4D (96 kw) (S05C) - - - ENGINE #AUTOCONF (2006-)
TOYOTA DIESEL ETIOS (NUK1-NGK1) 1.4 D-4D (50 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)
TOYOTA DIESEL ETIOS SEDAN (NGK1) 1.4 D-4D (50 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)
TOYOTA DIESEL HIACE FURG. (V TRH2-KDH2) 3.0 D (100 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2005-)
TOYOTA DIESEL HIACE FURG. (V TRH2-KDH2) 3.0 D (106 kw) (1KD-FTV) - - - ENGINE #AUTOCONF (2005-)
TOYOTA DIESEL HILUX PICK UP (III KUN) 2.8 D (125 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2005-)
TOYOTA DIESEL HILUX PICK UP (III KUN) 2.8 D 4WD (128 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2005-)
TOYOTA DIESEL IQ (GJ1-AJ) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL LAND CRUISER (J15) 2.8 D-4D (130 kw) (1GD-FTV) - - - ENGINE #AUTOCONF (2010-)
TOYOTA DIESEL URBAN CRUISER (NCP) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL URBAN CRUISER (NCP) 1.4 D-4D 4X4 (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL VERSO (AUR2-ZGR2) 1.6 D-4D (82 kw) (1WW) - - - ENGINE #AUTOCONF (2009-)
TOYOTA DIESEL VERSO MULTISPACE (II) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-2016)
TOYOTA DIESEL YARIS (III P13) 1.4 D-4D (66 kw) (1ND-TV) - - - ENGINE #AUTOCONF (2010-)

Adaptive value reset - GEARBOX ELECTRONICS

ALFA ROMEO GIULIA (952) ZF TCM (CAN) (2015-)

ALFA ROMEO STELVIO (949) ZF TCM (CAN) (2016-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

Memory reset - ABS-TRACTION CONTROL-ESP

Speed, transverse-longitudinal acceleration sensors setting - ABS-TRACTION CONTROL-ESP

Calibration of linear solenoid valve shifting - ABS-TRACTION CONTROL-ESP

Disable brake control (ECB) - ABS-TRACTION CONTROL-ESP

LEXUS CT (ZWA) - - - ABS - TYPE1 #AUTOCONF (2010-)

LEXUS ES (AVV6) - - - ABS - TYPE1 #AUTOCONF (2012-)

LEXUS ES (GSV4-ACV4) - - - ABS - TYPE1 #AUTOCONF (2006-2012)

LEXUS GS (GRL1-GWL1) - - - ABS - TYPE1 #AUTOCONF (2012-)

LEXUS GS (GWS-GRS-UZS) - - - ABS - TYPE1 #AUTOCONF (2005-2011)

LEXUS GX (URJ15) - - - ABS - TYPE1 #AUTOCONF (2010-)

LEXUS IS (GSE2-ALE2-USE2) - - - ABS - TYPE1 #AUTOCONF (2005-2013)

LEXUS IS (GSE3-AVE3) - - - ABS - TYPE1 #AUTOCONF (2013-)

LEXUS IS CABRIO (GSE2) - - - ABS - TYPE1 #AUTOCONF (2009-)

LEXUS LFA - - - ABS - TYPE1 #AUTOCONF (2010-2012)

LEXUS LS (UVF4-USF4) - - - ABS - TYPE1 #AUTOCONF (2006-)

LEXUS LX (URJ201) - - - ABS - TYPE1 #AUTOCONF (2007-)

LEXUS NX (ZGZ1-AYZ1-AGZ1) - - - ABS - TYPE1 #AUTOCONF (2014-)

LEXUS RC - - - ABS - TYPE1 #AUTOCONF (2014-)

LEXUS RX (AGL2-GGL2) - - - ABS - TYPE1 #AUTOCONF (2015-)

LEXUS RX (GYL1-GGL1-AGL1) - - - ABS - TYPE1 #AUTOCONF (2008-2015)

TOYOTA 4 RUNNER (TRN28-GRN28) - - - ABS - TYPE1 #AUTOCONF (2009-)

TOYOTA AURIS (E18) - - - ABS - TYPE1 #AUTOCONF (2012-)

TOYOTA AURIS (ZE15-RE15) - - - ABS - TYPE1 #AUTOCONF (2007-2012)

TOYOTA AURIS STATION WAGON (NDE18-ZRE18) - - - ABS - TYPE1 #AUTOCONF (2013-)

TOYOTA AURIS VAN (ZRE18-NZE18) - - - ABS - TYPE1 #AUTOCONF (2013-)

TOYOTA AURIS VAN - - - ABS - TYPE1 #AUTOCONF (2007-2013)

TOYOTA AVENSIS SEDAN (T27) - - - ABS - TYPE1 #AUTOCONF (2009-)

TOYOTA AVENSIS SPORTWAGON (T27) - - - ABS - TYPE1 #AUTOCONF (2009-)

TOYOTA AYGO (B10) - - - ABS - TYPE1 #AUTOCONF (2005-2014)

TOYOTA AYGO (MY2014) - - - ABS - TYPE1 #AUTOCONF (2014-)

TOYOTA C-HR (NGX1-NGX5-ZYX1) - - - ABS - TYPE1 #AUTOCONF (2016-)

TOYOTA CAMRY SEDAN (XV4) - - - ABS - TYPE1 #AUTOCONF (2006-2011)

TOYOTA CAMRY SEDAN (XV5) - - - ABS - TYPE1 #AUTOCONF (2011-)

TOYOTA COROLLA SEDAN (E15) - - - ABS - TYPE1 #AUTOCONF (2006-)

TOYOTA COROLLA SEDAN (E18) - - - ABS - TYPE1 #AUTOCONF (2013-)

TOYOTA COROLLA SEDAN (NZE16) - - - ABS - TYPE1 #AUTOCONF (2012-)

TOYOTA COROLLA STATION WAGON (NKE16-NZE16) - - - ABS - TYPE1 #AUTOCONF (2012-)

TOYOTA DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) - - - ABS - TYPE1 #AUTOCONF (2006-)

TOYOTA ETIOS (NUK1-NGK1) - - - ABS - TYPE1 #AUTOCONF (2010-)
 TOYOTA ETIOS SEDAN (NGK1) - - - ABS - TYPE1 #AUTOCONF (2010-)
 TOYOTA GT86 COUPÉ (ZN6) - - - ABS - TYPE1 #AUTOCONF (2012-)
 TOYOTA HIACE BUS (V CH1-CH2-XH1-XH2-LH1-LH2) - - - ABS - TYPE1 #AUTOCONF (2006-)
 TOYOTA HIACE FURG. (V TRH2-KDH2) - - - ABS - TYPE1 #AUTOCONF (2005-)
 TOYOTA HIACE WAGON (V H20) - - - ABS - TYPE1 #AUTOCONF (2006-)
 TOYOTA HILUX CASSONATO (IV GUN1) - - - ABS - TYPE1 #AUTOCONF (2016-)
 TOYOTA HILUX PICK UP (III KUN) - - - ABS - TYPE1 #AUTOCONF (2005-)
 TOYOTA HILUX PICK UP (IV GUN1) - - - ABS - TYPE1 #AUTOCONF (2016-)
 TOYOTA IQ (GJ1-AJ) - - - ABS - TYPE1 #AUTOCONF (2009-)
 TOYOTA LAND CRUISER (J15) - - - ABS - TYPE1 #AUTOCONF (2010-)
 TOYOTA LAND CRUISER (J20) - - - ABS - TYPE1 #AUTOCONF (2008-)
 TOYOTA LAND CRUISER (PRADO) - - - ABS - TYPE1 #AUTOCONF (2003-)
 TOYOTA LAND CRUISER PICK UP (J7) - - - ABS - TYPE1 #AUTOCONF (2007-)
 TOYOTA PREVIA (III ACR5-GSR5) - - - ABS - TYPE1 #AUTOCONF (2006-)
 TOYOTA PRIUS (W5) - - - ABS - TYPE1 #AUTOCONF (2016-)
 TOYOTA PRIUS (ZVW30) - - - ABS - TYPE1 #AUTOCONF (2009-)
 TOYOTA PRIUS C (NHP10) - - - ABS - TYPE1 #AUTOCONF (2012-)
 TOYOTA PRIUS PHV (W3) - - - ABS - TYPE1 #AUTOCONF (2012-)
 TOYOTA PRIUS PHV (W52) - - - ABS - TYPE1 #AUTOCONF (2016-)
 TOYOTA PRIUS PLUS (ZVW) - - - ABS - TYPE1 #AUTOCONF (2012-)
 TOYOTA RAV 4 (ALA4) - - - ABS - TYPE1 #AUTOCONF (2012-)
 TOYOTA RAV 4 (III ZSA-) - - - ABS - TYPE1 #AUTOCONF (2005-2013)
 TOYOTA URBAN CRUISER (NCP) - - - ABS - TYPE1 #AUTOCONF (2009-)
 TOYOTA VERSO (AUR2-ZGR2) - - - ABS - TYPE1 #AUTOCONF (2009-)
 TOYOTA VERSO MULTISPACE (II) - - - ABS - TYPE1 #AUTOCONF (2010-2016)
 TOYOTA YARIS (II P9) - - - ABS - TYPE1 #AUTOCONF (2006-2011)
 TOYOTA YARIS (III P13) - - - ABS - TYPE1 #AUTOCONF (2010-)
 TOYOTA YARIS (IV NCP15) - - - ABS - TYPE1 #AUTOCONF (2015-)
 TOYOTA YARIS SEDAN (ZSP9-NCP9) - - - ABS - TYPE1 #AUTOCONF (2007-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

Memory reset - ABS-TRACTION CONTROL-ESP

LEXUS CT (ZWA) - - - ABS - TYPE2 #AUTOCONF (2010-)
 LEXUS ES (AVV6) - - - ABS - TYPE2 #AUTOCONF (2012-)
 LEXUS ES (GSV4-ACV4) - - - ABS - TYPE2 #AUTOCONF (2006-2012)
 LEXUS GS (GRL1-GWL1) - - - ABS - TYPE2 #AUTOCONF (2012-)
 LEXUS GS (GWS-GRS-UZS) - - - ABS - TYPE2 #AUTOCONF (2005-2011)
 LEXUS GX (URJ15) - - - ABS - TYPE2 #AUTOCONF (2010-)
 LEXUS IS (GSE2-ALE2-USE2) - - - ABS - TYPE2 #AUTOCONF (2005-2013)
 LEXUS IS (GSE3-AVE3) - - - ABS - TYPE2 #AUTOCONF (2013-)
 LEXUS IS CABRIO (GSE2) - - - ABS - TYPE2 #AUTOCONF (2009-)
 LEXUS LFA - - - ABS - TYPE2 #AUTOCONF (2010-2012)
 LEXUS LS (UVF4-USF4) - - - ABS - TYPE2 #AUTOCONF (2006-)
 LEXUS LX (URJ201) - - - ABS - TYPE2 #AUTOCONF (2007-)
 LEXUS NX (ZGZ1-AYZ1-AGZ1) - - - ABS - TYPE2 #AUTOCONF (2014-)

LEXUS RC - - - ABS - TYPE2 #AUTOCONF (2014-)
 LEXUS RX (AGL2-GGL2) - - - ABS - TYPE2 #AUTOCONF (2015-)
 LEXUS RX (GYL1-GGL1-AGL1) - - - ABS - TYPE2 #AUTOCONF (2008-2015)
 TOYOTA 4 RUNNER (TRN28-GRN28) - - - ABS - TYPE2 #AUTOCONF (2009-)
 TOYOTA AURIS (E18) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA AURIS (ZE15-RE15) - - - ABS - TYPE2 #AUTOCONF (2007-2012)
 TOYOTA AURIS STATION WAGON (NDE18-ZRE18) - - - ABS - TYPE2 #AUTOCONF (2013-)
 TOYOTA AURIS VAN (ZRE18-NZE18) - - - ABS - TYPE2 #AUTOCONF (2013-)
 TOYOTA AURIS VAN - - - ABS - TYPE2 #AUTOCONF (2007-2013)
 TOYOTA AVENSIS SEDAN (T27) - - - ABS - TYPE2 #AUTOCONF (2009-)
 TOYOTA AVENSIS SPORTWAGON (T27) - - - ABS - TYPE2 #AUTOCONF (2009-)
 TOYOTA AYGO (B10) - - - ABS - TYPE2 #AUTOCONF (2005-2014)
 TOYOTA AYGO (MY2014) - - - ABS - TYPE2 #AUTOCONF (2014-)
 TOYOTA C-HR (NGX1-NGX5-ZYX1) - - - ABS - TYPE2 #AUTOCONF (2016-)
 TOYOTA CAMRY SEDAN (XV4) - - - ABS - TYPE2 #AUTOCONF (2006-2011)
 TOYOTA CAMRY SEDAN (XV5) - - - ABS - TYPE2 #AUTOCONF (2011-)
 TOYOTA COROLLA SEDAN (E15) - - - ABS - TYPE2 #AUTOCONF (2006-)
 TOYOTA COROLLA SEDAN (E18) - - - ABS - TYPE2 #AUTOCONF (2013-)
 TOYOTA COROLLA SEDAN (NZE16) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA COROLLA STATION WAGON (NKE16-NZE16) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA DYNA CAB. (KD-LY-TRY2-KDY2-XZU4) - - - ABS - TYPE2 #AUTOCONF (2006-)
 TOYOTA ETIOS (NUK1-NGK1) - - - ABS - TYPE2 #AUTOCONF (2010-)
 TOYOTA ETIOS SEDAN (NGK1) - - - ABS - TYPE2 #AUTOCONF (2010-)
 TOYOTA GT86 COUPÉ (ZN6) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA HIACE BUS (V CH1-CH2-XH1-XH2-LH1-LH2) - - - ABS - TYPE2 #AUTOCONF (2006-)
 TOYOTA HIACE FURG. (V TRH2-KDH2) - - - ABS - TYPE2 #AUTOCONF (2005-)
 TOYOTA HIACE WAGON (V H20) - - - ABS - TYPE2 #AUTOCONF (2006-)
 TOYOTA HILUX CASSONATO (IV GUN1) - - - ABS - TYPE2 #AUTOCONF (2016-)
 TOYOTA HILUX PICK UP (III KUN) - - - ABS - TYPE2 #AUTOCONF (2005-)
 TOYOTA HILUX PICK UP (IV GUN1) - - - ABS - TYPE2 #AUTOCONF (2016-)
 TOYOTA IQ (GJ1-AJ) - - - ABS - TYPE2 #AUTOCONF (2009-)
 TOYOTA LAND CRUISER (J15) - - - ABS - TYPE2 #AUTOCONF (2010-)
 TOYOTA LAND CRUISER (J20) - - - ABS - TYPE2 #AUTOCONF (2008-)
 TOYOTA LAND CRUISER (PRADO) - - - ABS - TYPE2 #AUTOCONF (2003-)
 TOYOTA LAND CRUISER PICK UP (J7) - - - ABS - TYPE2 #AUTOCONF (2007-)
 TOYOTA PREVIA (III ACR5-GSR5) - - - ABS - TYPE2 #AUTOCONF (2006-)
 TOYOTA PRIUS (W5) - - - ABS - TYPE2 #AUTOCONF (2016-)
 TOYOTA PRIUS (ZVW30) - - - ABS - TYPE2 #AUTOCONF (2009-)
 TOYOTA PRIUS C (NHP10) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA PRIUS PHV (W3) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA PRIUS PHV (W52) - - - ABS - TYPE2 #AUTOCONF (2016-)
 TOYOTA PRIUS PLUS (ZVW) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA RAV 4 (ALA4) - - - ABS - TYPE2 #AUTOCONF (2012-)
 TOYOTA RAV 4 (III ZSA-) - - - ABS - TYPE2 #AUTOCONF (2005-2013)
 TOYOTA URBAN CRUISER (NCP) - - - ABS - TYPE2 #AUTOCONF (2009-)
 TOYOTA VERSO (AUR2-ZGR2) - - - ABS - TYPE2 #AUTOCONF (2009-)
 TOYOTA VERSO MULTISPACE (II) - - - ABS - TYPE2 #AUTOCONF (2010-2016)

TOYOTA YARIS (II P9) - - - ABS - TYPE2 #AUTOCONF (2006-2011)
TOYOTA YARIS (III P13) - - - ABS - TYPE2 #AUTOCONF (2010-)
TOYOTA YARIS (IV NCP15) - - - ABS - TYPE2 #AUTOCONF (2015-)
TOYOTA YARIS SEDAN (ZSP9-NCP9) - - - ABS - TYPE2 #AUTOCONF (2007-)

Longitudinal acceleration sensor calibration - ABS-TRACTION CONTROL-ESP

HYUNDAI I10 (IA) - - - ABS (CAN) (2013-)

Lateral acceleration sensor calibration - ABS-TRACTION CONTROL-ESP

HYUNDAI I10 (IA) - - - ABS (CAN) (2013-)

Brake pedal calibration - ABS-TRACTION CONTROL-ESP

HYUNDAI I10 (IA) - - - ABS (CAN) (2013-)

Valve flushing - ABS-TRACTION CONTROL-ESP

HYUNDAI I10 (IA) - - - ABS (CAN) (2013-)

System self-test - AC SYSTEM

ABARTH 124 SPIDER (348) - - - HVAC (CAN) (2016-)
FIAT 124 SPIDER (MY2016) - - - HVAC (CAN) (2016-)
MAZDA MX 5 (ND) - - - HVAC (CAN) (2015-)
MAZDA MX 5 RF (ND) - - - HVAC (CAN) (2016-)

EPS type recognition - POWERSTEERING

HYUNDAI I10 (IA) - - - MDPS (CAN) (2013-)

Variant code - INSTRUMENT CLUSTER

HYUNDAI I10 (IA) - - - CLUSTER (CAN) (2013-)

Gateway initialisation - BODY COMPUTER

TOYOTA YARIS (IV NCP15) - - - BODY (CAN) (2015-)

Equipment/Accessories setup - BODY COMPUTER

KIA SPORTAGE STATION WAGON (QL) - - - BCM (CAN) (2015-)

Equipment/Accessories setup - BODY COMPUTER

HYUNDAI I10 (IA) - - - BCM (CAN) (2013-)

Door unlocking based on key removal - BODY COMPUTER

HYUNDAI I10 (IA) - - - BCM (CAN) (2013-)

Door unlocking disabled - BODY COMPUTER

HYUNDAI I10 (IA) - - - BCM (CAN) (2013-)

Equipment/Accessories setup - CONNECTION BOX ELECTRONICS

HYUNDAI I10 (IA) - - - SJB (CAN) (2013-)

Stores vehicle VIN?into ECU - TIRE PRESSURE CHECK

HYUNDAI TUCSON - - - TPMS (CAN) (2015-)

Left-hand drive and manual transmission variant coding - PARKING ASSIST

KIA SORENTO (II XM) - - - PARK ASSIST (CAN) (2009-)

Right-hand drive and manual transmission variant coding - PARKING ASSIST

KIA SORENTO (II XM) - - - PARK ASSIST (CAN) (2009-)

Left-hand drive and automatic transmission variant coding - PARKING ASSIST

KIA SORENTO (II XM) - - - PARK ASSIST (CAN) (2009-)

Right-hand drive and automatic transmission variant coding - PARKING ASSIST

KIA SORENTO (II XM) - - - PARK ASSIST (CAN) (2009-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

Memory reset - ELECTRIC HANDBRAKE

LEXUS CT (ZWA) - - - EPB #AUTOCONF (2010-)

LEXUS GS (GRL1-GWL1) - - - EPB #AUTOCONF (2012-)

LEXUS GS (GWS-GRS-UZS) - - - EPB #AUTOCONF (2005-2011)

LEXUS IS (GSE2-ALE2-USE2) - - - EPB #AUTOCONF (2005-2013)

LEXUS IS (GSE3-AVE3) - - - EPB #AUTOCONF (2013-)

LEXUS IS CABRIO (GSE2) - - - EPB #AUTOCONF (2009-)

LEXUS LFA - - - EPB #AUTOCONF (2010-2012)

LEXUS LS (UVF4-USF4) - - - EPB #AUTOCONF (2006-)

LEXUS LX (URJ201) - - - EPB #AUTOCONF (2007-)

LEXUS NX (ZGZ1-AYZ1-AGZ1) - - - EPB #AUTOCONF (2014-)
LEXUS RC - - - EPB #AUTOCONF (2014-)
LEXUS RX (AGL2-GGL2) - - - EPB #AUTOCONF (2015-)
LEXUS RX (GYL1-GGL1-AGL1) - - - EPB #AUTOCONF (2008-2015)
TOYOTA AURIS (E18) - - - EPB #AUTOCONF (2012-)
TOYOTA AURIS (ZE15-RE15) - - - EPB #AUTOCONF (2007-2012)
TOYOTA AURIS STATION WAGON (NDE18-ZRE18) - - - EPB #AUTOCONF (2013-)
TOYOTA AURIS VAN (ZRE18-NZE18) - - - EPB #AUTOCONF (2013-)
TOYOTA AURIS VAN - - - EPB #AUTOCONF (2007-2013)
TOYOTA AVENSIS SEDAN (T27) - - - EPB #AUTOCONF (2009-)
TOYOTA AVENSIS SPORTWAGON (T27) - - - EPB #AUTOCONF (2009-)
TOYOTA C-HR (NGX1-NGX5-ZYX1) - - - EPB #AUTOCONF (2016-)
TOYOTA PRIUS (W5) - - - EPB #AUTOCONF (2016-)
TOYOTA PRIUS (ZVW30) - - - EPB #AUTOCONF (2009-)
TOYOTA PRIUS C (NHP10) - - - EPB #AUTOCONF (2012-)
TOYOTA PRIUS PHV (W3) - - - EPB #AUTOCONF (2012-)
TOYOTA PRIUS PHV (W52) - - - EPB #AUTOCONF (2016-)
TOYOTA PRIUS PLUS (ZVW) - - - EPB #AUTOCONF (2012-)
TOYOTA RAV 4 (ALA4) - - - EPB #AUTOCONF (2012-)
TOYOTA RAV 4 (III ZSA-) - - - EPB #AUTOCONF (2005-2013)

System initialization activation - HATCHBACK-REAR DOORS

MERCEDES-BENZ CLASSE E (W213) TEMIC KDS (CAN) (2016-)
MERCEDES-BENZ CLASSE E ALL-TERRAIN (S213) TEMIC KDS (CAN) (2017-)
MERCEDES-BENZ CLASSE E CABRIO (A238) TEMIC KDS (CAN) (2017-)
MERCEDES-BENZ CLASSE E COUPÉ (C238) TEMIC KDS (CAN) (2017-)
MERCEDES-BENZ CLASSE E STATION WAGON (S213) TEMIC KDS (CAN) (2016-)

Autoconfiguring system !! The functions listed below may be available or not, depending on the vehicle / diagnostic setup

Gateway initialisation - BODY GATEWAY MODULE

LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (110 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
LEXUS DIESEL IS (GSE2-ALE2-USE2) 220 D (130 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
LEXUS GASOLINE ES (AVV6) 250 (135 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
LEXUS GASOLINE ES (AVV6) 350 (204 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
LEXUS GASOLINE ES (GSV4-ACV4) 3.5 (204 kw) (- - -) - - - GATEWAY #AUTOCONF (2006-2012)
LEXUS GASOLINE GS (GRL1-GWL1) 250 (158 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
LEXUS GASOLINE GS (GRL1-GWL1) 350 (233 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
LEXUS GASOLINE GS (GRL1-GWL1) F (348 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
LEXUS GASOLINE GS (GRL1-GWL1) F (351 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
LEXUS GASOLINE GS (GRL1-GWL1) GS 250 (154 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
LEXUS GASOLINE GS (GWS-GRS-UZS) 3.0 (170 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
LEXUS GASOLINE GS (GWS-GRS-UZS) 300 (183 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
LEXUS GASOLINE GS (GWS-GRS-UZS) 300 AWD (183 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
LEXUS GASOLINE GS (GWS-GRS-UZS) 350 (226 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
LEXUS GASOLINE GS (GWS-GRS-UZS) 350 (232 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)

LEXUS GASOLINE GS (GWS-GRS-UZS) 350 AWD (226 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS GASOLINE GS (GWS-GRS-UZS) 350 AWD (232 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS GASOLINE GS (GWS-GRS-UZS) 4.3 VVTI (221 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS GASOLINE GS (GWS-GRS-UZS) 430 (208 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS GASOLINE GS (GWS-GRS-UZS) 430 (216 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS GASOLINE GS (GWS-GRS-UZS) 460 (255 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS GASOLINE IS (GSE2-ALE2-USE2) 250 (153 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
 LEXUS GASOLINE IS (GSE2-ALE2-USE2) 250 AWD (152 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
 LEXUS GASOLINE IS (GSE2-ALE2-USE2) 350 (228 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
 LEXUS GASOLINE IS (GSE2-ALE2-USE2) 350 (234 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
 LEXUS GASOLINE IS (GSE2-ALE2-USE2) 350 AWD (228 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
 LEXUS GASOLINE IS (GSE2-ALE2-USE2) IS F (311 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2013)
 LEXUS GASOLINE IS (GSE3-AVE3) 250 (153 kw) (- - -) - - - GATEWAY #AUTOCONF (2013-)
 LEXUS GASOLINE IS CABRIO (GSE2) 250 (153 kw) (- - -) - - - GATEWAY #AUTOCONF (2009-)
 LEXUS GASOLINE IS CABRIO (GSE2) 300 (170 kw) (- - -) - - - GATEWAY #AUTOCONF (2009-)
 LEXUS GASOLINE IS CABRIO (GSE2) 350 (228 kw) (- - -) - - - GATEWAY #AUTOCONF (2009-)
 LEXUS GASOLINE IS CABRIO (GSE2) 350 (234 kw) (- - -) - - - GATEWAY #AUTOCONF (2009-)
 LEXUS GASOLINE LFA 4.8 (412 kw) (- - -) - - - GATEWAY #AUTOCONF (2010-2012)
 LEXUS GASOLINE LFA 4.8 (420 kw) (- - -) - - - GATEWAY #AUTOCONF (2010-2012)
 LEXUS GASOLINE LX (URJ201) 570 (270 kw) (- - -) - - - GATEWAY #AUTOCONF (2007-)
 LEXUS GASOLINE RC 200T (180 kw) (- - -) - - - GATEWAY #AUTOCONF (2014-)
 LEXUS GASOLINE RC 350 (234 kw) (- - -) - - - GATEWAY #AUTOCONF (2014-)
 LEXUS GASOLINE RC F (348 kw) (- - -) - - - GATEWAY #AUTOCONF (2014-)
 LEXUS GASOLINE RC F (351 kw) (- - -) - - - GATEWAY #AUTOCONF (2014-)
 LEXUS GASOLINE RX (AGL2-GGL2) 200T (175 kw) (- - -) - - - GATEWAY #AUTOCONF (2015-)
 LEXUS GASOLINE RX (AGL2-GGL2) 200T AWD (175 kw) (- - -) - - - GATEWAY #AUTOCONF (2015-)
 LEXUS GASOLINE RX (AGL2-GGL2) 350 (220 kw) (- - -) - - - GATEWAY #AUTOCONF (2015-)
 LEXUS GASOLINE RX (AGL2-GGL2) 350 4WD (220 kw) (- - -) - - - GATEWAY #AUTOCONF (2015-)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 270 (138 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 3.5 AWD (183 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (201 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (202 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (204 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 (205 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (201 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (202 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (204 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS GASOLINE RX (GYL1-GGL1-AGL1) 350 AWD (205 kw) (- - -) - - - GATEWAY #AUTOCONF (2008-2015)
 LEXUS HYBRID ES (AVV6) 300H (118 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
 LEXUS HYBRID GS (GRL1-GWL1) 450H (217 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
 LEXUS HYBRID GS (GRL1-GWL1) GS 300H (133 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
 LEXUS HYBRID GS (GRL1-GWL1) GS 450H (215 kw) (- - -) - - - GATEWAY #AUTOCONF (2012-)
 LEXUS HYBRID GS (GWS-GRS-UZS) 450 H (218 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS HYBRID GS (GWS-GRS-UZS) 450 H (254 kw) (- - -) - - - GATEWAY #AUTOCONF (2005-2011)
 LEXUS HYBRID IS (GSE3-AVE3) 300H (131 kw) (- - -) - - - GATEWAY #AUTOCONF (2013-)
 LEXUS HYBRID RC 300H (131 kw) (- - -) - - - GATEWAY #AUTOCONF (2014-)
 LEXUS HYBRID RX (AGL2-GGL2) 450H (230 kw) (- - -) - - - GATEWAY #AUTOCONF (2015-)

LEXUS HYBRID RX (AGL2-GGL2) 450H AWD (193 kw) (---) --- GATEWAY #AUTOCONF (2015-)
 LEXUS HYBRID RX (AGL2-GGL2) 450H AWD (230 kw) (---) --- GATEWAY #AUTOCONF (2015-)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 350H (220 kw) (---) --- GATEWAY #AUTOCONF (2008-2015)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 350H AWD (220 kw) (---) --- GATEWAY #AUTOCONF (2008-2015)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 450H (183 kw) (---) --- GATEWAY #AUTOCONF (2008-2015)
 LEXUS HYBRID RX (GYL1-GGL1-AGL1) 450H AWD (183 kw) (---) --- GATEWAY #AUTOCONF (2008-2015)
 TOYOTA BIFUEL COROLLA SEDAN (E15) 1.6 CNG (80 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA BIFUEL COROLLA SEDAN (E18) 1.6 16V VVT-I (91 kw) (---) --- GATEWAY #AUTOCONF (2013-)
 TOYOTA DIESEL COROLLA SEDAN (E15) 1.4 D-4D (66 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA DIESEL COROLLA SEDAN (E15) 2.0 D-4D (93 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA DIESEL COROLLA SEDAN (E15) 2.2 D-4D (130 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA DIESEL COROLLA SEDAN (E18) 1.4 D-4D (66 kw) (---) --- GATEWAY #AUTOCONF (2013-)
 TOYOTA DIESEL LAND CRUISER (J15) 2.8 D-4D (130 kw) (---) --- GATEWAY #AUTOCONF (2010-)
 TOYOTA DIESEL LAND CRUISER (J15) 3.0 D-4D (127 kw) (---) --- GATEWAY #AUTOCONF (2010-)
 TOYOTA DIESEL LAND CRUISER (J15) 3.0 D-4D (140 kw) (---) --- GATEWAY #AUTOCONF (2010-)
 TOYOTA DIESEL LAND CRUISER (J20) 4.5 D V8 (200 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA DIESEL LAND CRUISER (J20) 4.5 D V8 (210 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA DIESEL LAND CRUISER (J20) 4.5 D-40 V8 (195 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA DIESEL LAND CRUISER (J20) 4.5 V8 D-4D (200 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA DIESEL LAND CRUISER (J20) 4.5 V8 D-4D (210 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA DIESEL LAND CRUISER PICK UP (J7) 4.2 D (96 kw) (---) --- GATEWAY #AUTOCONF (2007-)
 TOYOTA DIESEL LAND CRUISER PICK UP (J7) 4.2 TD 4X4 (100 kw) (---) --- GATEWAY #AUTOCONF (2007-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 2.7 (116 kw) (---) --- GATEWAY #AUTOCONF (2009-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 2.7 4WD (117 kw) (---) --- GATEWAY #AUTOCONF (2009-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 4.0 (201 kw) (---) --- GATEWAY #AUTOCONF (2009-)
 TOYOTA GASOLINE 4 RUNNER (TRN28-GRN28) 4.0 4WD (201 kw) (---) --- GATEWAY #AUTOCONF (2009-)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 2.0 VVT-I (108 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 2.4 VVTI (116 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 2.4 VVTI (123 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 2.4 VVTI (127 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 2.5 (133 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 2.5 VVTI (124 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 2.5 VVTI (129 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 3.5 (200 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 3.5 (204 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV4) 3.5 (209 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 2.0 (109 kw) (---) --- GATEWAY #AUTOCONF (2011-)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 2.5 (133 kw) (---) --- GATEWAY #AUTOCONF (2011-)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 3.5 (204 kw) (---) --- GATEWAY #AUTOCONF (2011-)
 TOYOTA GASOLINE CAMRY SEDAN (XV5) 3.5 V6 (183 kw) (---) --- GATEWAY #AUTOCONF (2011-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.3 VVT-I (63 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.33 (73 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.4 VVT-I (71 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.5 (81 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.5 4WD (77 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.6 VVT-I (79 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.6 VVT-I (81 kw) (---) --- GATEWAY #AUTOCONF (2006-)

TOYOTA GASOLINE COROLLA SEDAN (E15) 1.6 VVT-I (91 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.6 VVT-I (97 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 (106 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 4WD (98 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVT-I (108 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVTI (103 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E15) 1.8 VVTL-I (100 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.3 (73 kw) (---) --- GATEWAY #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.6 (97 kw) (---) --- GATEWAY #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.6 16V VVT-I (91 kw) (---) --- GATEWAY #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.8 (103 kw) (---) --- GATEWAY #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (E18) 1.8 16V VVT-I (103 kw) (---) --- GATEWAY #AUTOCONF (2013-)
 TOYOTA GASOLINE COROLLA SEDAN (NZE16) 1.3 (70 kw) (---) --- GATEWAY #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA SEDAN (NZE16) 1.5 (80 kw) (---) --- GATEWAY #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA SEDAN (NZE16) 1.5 4WD (76 kw) (---) --- GATEWAY #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA STATION WAGON (NKE16-NZE16) 1.5 (80 kw) (---) --- GATEWAY #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA STATION WAGON (NKE16-NZE16) 1.5 4WD (76 kw) (---) --- GATEWAY #AUTOCONF (2012-)
 TOYOTA GASOLINE COROLLA STATION WAGON (NKE16-NZE16) 1.8 (103 kw) (---) --- GATEWAY #AUTOCONF (2012-)
 TOYOTA GASOLINE LAND CRUISER (J15) 2.7 (120 kw) (---) --- GATEWAY #AUTOCONF (2010-)
 TOYOTA GASOLINE LAND CRUISER (J15) 4.0 (207 kw) (---) --- GATEWAY #AUTOCONF (2010-)
 TOYOTA GASOLINE LAND CRUISER (J15) 4.0 V6 VVT-I (207 kw) (---) --- GATEWAY #AUTOCONF (2010-)
 TOYOTA GASOLINE LAND CRUISER (J20) 4.0 VVTI (176 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (J20) 4.6 V8 (234 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (J20) 4.7 V8 (175 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (J20) 4.7 V8 (212 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (J20) 5.7 V8 (268 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (J20) 5.7 V8 (284 kw) (---) --- GATEWAY #AUTOCONF (2008-)
 TOYOTA GASOLINE LAND CRUISER (PRADO) 4.0 VVTI (176 kw) (---) --- GATEWAY #AUTOCONF (2003-)
 TOYOTA GASOLINE LAND CRUISER PICK UP (J7) 4.0 4X4 (170 kw) (---) --- GATEWAY #AUTOCONF (2007-)
 TOYOTA GASOLINE LAND CRUISER PICK UP (J7) 4.5 MPFI 4X4 (179 kw) (---) --- GATEWAY #AUTOCONF (2007-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 2.4 (125 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 3.5 (200 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 3.5 (206 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA GASOLINE PREVIA (III ACR5-GSR5) 3.5 4WD (206 kw) (---) --- GATEWAY #AUTOCONF (2006-)
 TOYOTA HYBRID CAMRY SEDAN (XV4) 2.4 HYBRID (139 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA HYBRID CAMRY SEDAN (XV4) 2.4 VVT-I HYBRID (110 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA HYBRID CAMRY SEDAN (XV4) 2.4 VVTI HYBRID (105 kw) (---) --- GATEWAY #AUTOCONF (2006-2011)
 TOYOTA HYBRID CAMRY SEDAN (XV5) 2.5 HYBRID (118 kw) (---) --- GATEWAY #AUTOCONF (2011-)
 TOYOTA HYBRID PREVIA (III ACR5-GSR5) 2.4 HYBRID (110 kw) (---) --- GATEWAY #AUTOCONF (2006-)