

Complete Kit

- Often, the injector is locked in its seat due to fouling caused by burning and can not be removed without a proper tool.
 - WORKING: Mechanical
- Specific for disassembling very locked injectors.
 - The advantage of the supporting feet adjustment, on the fixing screws of the head, ensures its use in different levels (right and left); as well as the possibility to adjust the slippage of the two side bars.

Components

| Centering | 311166003 | PÂ |
|---------------------------|-----------|---------|
| Support plate | 311166002 | Ð |
| Adjustable levelling foot | 311166001 | <u></u> |
| M18x1.5 - L=220 mm screw | 311146011 | 0 |
| 10 mm wrench | 311026014 | ETE |
| M18x1.5 CH30 nut | 311070006 | 6 |



Components

•

Foot extension kit

311166009



Lower support



The adjustment, therefore, takes place both in height and

311 166 010

► INJECTORS: Bosch, Delphi, Siemens, Denso

width according to the conformity of the engine head.

Universa

| Components | | | Com |
|--|-----------|-------|--------------|
| Foot extension | 311142007 | | CH2 DEN |
| Washer | 311083004 | | CH2 SIE/V |
| Bracket | 311070030 | | CH2 SIE/V |
| M18x1.5 mm double connection screw - BOSCH | 311166005 | (I) | Femc M18 |
| CH24 - M14x1.5 adapter - DELPHI | 311146013 | OF. | Male M18 |
| CH24 - M16x1 adapter - TOYOTA | 311146014 | - AND | |

Components

| CH24 - M20x1 adapter - DENSO | 311146015 | T |
|--------------------------------------|-----------|-------|
| CH24 - M25x1 adapter - SIEMENS | 311146016 | DE |
| CH24 - M27x1 adapter - SIEMENS | 311146017 | DE |
| Female extension / female M18x1.5 | 311166007 | 0P |
| Male extension/female M18x1.5 | 311166008 | de la |
| | | |

The kit is suitable for the extraction of numerous models of injectors specifically M17x1 for Bosch, M14x1 for Delphi models, Toyota with adapter M16x1, M20x1 used for the extraction of Denso injectors and finally M25x1 and M27x1 for Siemens.

This kit can be used directly on the vehicle, with the engine mounted; its **mechanical operation** in fact, allows it to be used in confined spaces or in the far back position near the passenger compartment.



